

Operation Description

1. After power on, the MCU will turn on ASK module for 4sec to test the ASK module function.
2. ASK module is off. MCU make rainfall measurement.
3. Rainfall data is sent out through the ASK module.
4. Within the first 8 transmissions, the MCU will transmit weather related data every 8 seconds.
5. During the time span of 48s, rainfall data is measured periodically.