BTH033-KMA26 Bluetooth stereo headset User's manual



Contents

■ Brief introduction	1
1. Bluetooth wireless communication technology	1
2. About BTH033-KMA26	1
■ Before use	2
1. Overview	2
2. Charging for Headsets	3
■ Getting started	4
1. Turning on/off the headsets	4
2. Pairing headsets with Bluetooth devices	4
1) How to enter pairing mode	4
2) Pairing headsets with a Bluetooth cell phone	5
3) Pairing headsets with a Bluetooth transmitter	5
4) Pairing headsets with Multi-devices	6
3. Re-connecting with a Bluetooth device	7
4. Making calls with the headset	7
5. Playing music	9
6. LED indicator	11
7. Indication tone	
8. Factory Reset	11
■ Care and maintenance	
■ FAQs	
■ Specification	. 13

Welcome to use this Bluetooth stereo headset, BTH033-KMA26. Please read this user's manual carefully before use.

■ Brief introduction

1. Bluetooth wireless communication technology

Bluetooth is a standard of close range wireless communication technology that was drawn up by Ericsson, IBM, Intel, Nokia and Toshiba. With Bluetooth technology, we can achieve the highest transmission rate among cell phones, computers, printers, PDAs and other devices. The max transmission range of class II is 10 meters while the max transmission ranges of class I can reach up to 100 meters.

2. About BTH033-KMA26

BTH033-KMA26 is a Bluetooth stereo headset. Foldable and retractable design is very easy to take with you. It supports the following Bluetooth profiles:

HSP — Headset Profile

HFP — Hands-free Profile

A2DP —— Advanced Audio Distribution Profile

AVRCP----Audio/Video Remote Control Profile

You can enjoy music wirelessly by using BTH033-KMA26. It has the following features:

- 1) Pairing with a Bluetooth cell phone or PDA supporting HFP profile.
- Answer a call, end a call and reject a call
- · Redial last number
- ♦ Voice dial
- · Adjust the volume
- · Call transfer between the headset and your Bluetooth cell phone
- ♦ Microphone mute
- Pairing with a Bluetooth cell phone or Bluetooth transmitter supporting A2DP profile.
- · Enjoy music wirelessly
- · Adjust the volume
- · Remote control pause/play
- Remote control previous/next track

- 3) Easy to switch between the call and music, you will not miss the incoming call during listening to music.
- 4) Every time the headset is turned on, it will connect to last connected device automatically.

Note: In order to complete above function, the Bluetooth profiles of paired device must be same as the headset. And even though the paired device and the headset support the same Bluetooth profiles, functions may vary due to specification differences of the paired devices.

■ Before use

1. Overview





1	Built-in Microphone	7	LED indicator
2	Multi-function button(MFB)	8	Charging jack
3	Next song	9	Volume down
4	Pause/play	10	Volume up
5	Last song	11	Right speaker
6	Line-in jack	12	Left speaker

2. Charging the headset

The headset comes with a built-in rechargeable battery, prior to using it, it is recommended to charge the battery fully for the first time.

When the headset is low power, the headset emits three "Dong" tones every 30 seconds and the red LED flashes. Please recharge the battery of the headset

The way of charging as following:

Using USB cable

- 1. Plug USB charging cable into the USB port of computer
- 2. Plug another side of USB cable to headset

Red light on: Charging

Blue light on: Finish charging

3. It will takes about 3 hours to finish charging



Remarks:

- 1) The battery is recyclable.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

■ Getting started

1. Turning on/off the headset

Functions	Operation	LED indicator
Turning on	Press and hold MFB button for	Blue light on one
	3 seconds until blue LED	second
	flashes	
Turning off	Press and hold MFB button for	Red light on one
	3 seconds until red LED	second
	flashes	

Remark: In order to save power, the headset will turn off automatically if no devices can be connected after 5 minutes.

2. Pairing the headset with Bluetooth devices

1) How to enter pairing mode

Functions	Operation	LED indicator
Enter	Ensure the headset is off, and	Red and blue LED
pairing	then press and hold MFB	flash alternately
mode	button for 5~6 seconds until red	
	and blue LED flash alternately	

Remark: Pairing mode will last 2 minutes. If no devices can be connected after 2 minutes, it will return to standby mode automatically.

2) Pairing the headset with a Bluetooth cell phone

Prior to using the headset for the first time, you have to pair it with a Bluetooth-enabled cell phone. The pairing procedures are subject to different models of cell phones. Please refer to your cell phone user's manual for further information. The general pairing procedures are as follows:

- Keep your headset and phone within 1 meter when pairing;
- Make the headset enter pairing mode (please refer to "How to enter pairing mode);
- Activate your cell phone's Bluetooth function and set your cell phone to search for Bluetooth devices within range, and select "BTH033-KMA26" from the list of devices shown;
- According to the indication, enter password or PIN No: "0000" (If the mobile phone supports Bluetooth V2.1, password is not required.);
- If prompted by your cell phone to connect, select "Yes" (this will vary among cell phone models);
- 6) After successful connecting, blue LED flashes twice every 4 seconds.

Remarks:

- ◆ If pairing is failed, please turn off the headset first and then re-pair according to steps 1~6 mentioned above.
- After pairing is successful, the headset and the cell phone will remember each other, they will no need to re-pair next time. The headset can remember 8 paired devices, when the number of paired devices exceeds 8, the first one will be replaced.
- ◆ Every time the headset is turned on, it will connect to last connected device automatically. If you want to pair it with other devices, please turn off the Bluetooth function of last connected devices first and pair the headset with the new device according to steps 1 ~6 mentioned above.

3) Pairing the headset with a Bluetooth transmitter

You can connect the headset to a Bluetooth transmitter to enjoy music wirelessly. Hereby take BTT005 (Bluetooth transmitter, not included in accessories) for example. The pairing steps are as follows:

- Keep your headset and transmitter within 1 meter when pairing;
- Make the headset enter pairing mode (Please refer to "How to enter pairing mode);
- Turn on the Bluetooth transmitter and make it enter paring mode. It will search for Bluetooth devices automatically and send a pairing request;
- 5
- 4) When the headset requests to enter a PIN No., the transmitter will response "0000" automatically:
- After successful pairing and connecting, blue LED of the headset flashes twice every 4 seconds.

Remarks:

- The pairing password of BTH033-KMA26 is "0000". So, the headset can only pair with a Bluetooth transmitter whose pairing password is "0000".
- If pairing still fails after several tries, please refer to the Bluetooth transmitter's user's manual for further information.

4) Pairing headsets with Multi-devices

The headset can connect with two Bluetooth devices at most. If you want to finish the multi-pairing, please refer to the following steps:

- Firstly, pair and connect the headset with Bluetooth device one (refer to "pairing the headset with a Bluetooth cell phone);
- Turn off the headset and make it enter paring mode again, pair and connect with Bluetooth device two(refer to "pairing the headset with a Bluetooth cell phone);
- 3) Operate Bluetooth device one to connect with headset. The headset has already connected with Bluetooth device one and two, the headset also can connect with these two devices automatically next time.

Remarks:

- After successful multi-pairing, the paired devices will remember each other.
- The headset will connect with last connected two devices automatically after turn on.

 Multi-pair function is off in factory set, the steps of turn on as follows: Turn off multi-pair function: the headset in standby mode, not connect with device, press MFB and volume down button for 3-5 seconds simultaneously and release it until hear a prompt tone.

Turn on multi-pair function: the headset in standby mode, not connect with device, press MFB and volume up button for 3~5 seconds simultaneously and release it until hear a prompt tone.

 To improve the stabilization of headset, we suggest you turn off the multi-pair function when you only connect with one cell phone.

3. Re-connecting with a Bluetooth device

1) Automatic connecting

Every time the headset is turned on, it will connect to last connected device automatically.

2) Manual connecting

When the headset is in standby mode and not connect with device, short press any button of headset, it will connect to last connected device.

Remarks:

- Before connecting to a Bluetooth device, please turn on the Bluetooth function of Bluetooth device.
- On some Bluetooth devices, take some Nokia cell phones for example, you have to allow automatic connecting in the cell phone's settings. Please refer to your cell phone's manual for further information.

4. Making a call with the headset

1) Basic operation

Functions	Status of headset	Operation
Cancel a call	Calling	Short press MFB once
Answer a call	Incoming ringing	Short press MFB once
Reject a call	Incoming ringing	Long press MFB for 2 seconds and release it until listen a tone
End a call	During a call	Short press MFB once
Volume up	During a call	Short or long press + button
Volume down	During a call	Short or long press — button

Transfer conversation to mobile phone	During a call	Long press MFB for 2 seconds
Transfer conversation to headset	During a call	Long press MFB for 2 seconds
Microphone mute	During a call	Double click MFB
Cancel mute	During a call (microphone mute)	Double click MFB
Voice dial	Standby mode (connected device)	Long press ▶ button for 2 seconds
Redial the last number	Standby mode (connected device)	Double click MFB

2) Three-ways call operation

Functions	Status of headsets	Operation
Answer new call and	There are second	Short press ▶∥
end current call	incoming call	once
Answer new call and	There are second	Long press ▶∥ for
retain current call	incoming call	2 seconds
Reject new call and	There are second	Double click ▶∥
keep current call	incoming call	button
Switch calls	Keep conversation	Long press ►∥ for
		2 seconds
End current call and	Keep conversation	Short press ▶ once
switch retain call		
End retain call and	Keep conversation	Double click ▶∥
keep current call		button

Warning: Excessive pressure from earphones and headphones can cause hearing loss.

Note:

- Not all the mobile phones support all the functions listed above. Please refer to your mobile phone user's manual.
- ◆ Different function and prompt tone according to different mobile phone.
- When the volume is adjusted to max or min, you will hear one prompt tone.
- When pressing the answer button on some mobile phones, the call will be transferred to the mobile phone. You can switch the call to the headset by using the conversation switch button or through operating on the mobile phone. Please refer to your mobile phone user manual for further information

3) Connecting with two cell phones to make a call

Functions	Status of headset	Operation
Retain phone call #1	During phone call #1,	Long press ▶∥ for
and answer phone	phone 2 has incoming	2 seconds
call #2	call	
End phone call #1 and answer phone	During phone call #1, phone 2 has incoming	Short press ►∥ once
call #2	call	
Reject phone call	During phone call #1,	Double click ▶∥
#2 and keep current phone call	phone 2 has incoming call	button
Switch call	During call, one of	Long press ▶∥ for
	phone call is retained	2 seconds
End current call,	During call, one of	Short press ▶∥
back to retain phone	phone call is retained	once
call		
End retain phone	During call, one of	Double click ▶∥
call	phone call is retained	button

5. Playing music

When the headset connects to a mobile phone or Bluetooth transmitter which supports A2DP, you can enjoy music wirelessly through the headset.

Func	tion	Status of the headset	Operation
Volum	e up	Playing music	Short press "+"button

Volume	Playing music	Short press "-"button
down		
Last song	Playing music	Short press ◀ button once
Next song	Playing music	Short press ▶ button once
Fast	Playing music	Long press ▶ button once
forward	' -	
Fast rewind	Playing music	Long press ◀ button once
Pause	Playing music	Short press ▶∥ button once
play	Pausing	Short press ▶∥ button once
Line in	Turned off	It can playing music through 3.5mm
input		audio line

Notes:

- When playing music on some mobile phones, the music will be transmitted to the mobile phone's speaker instead of the headset. You have to select "transmit the sound via Bluetooth" in the settings menu and then choose "BTH033-KMA26" as speaker device. The music will be transmitted to the headset. Please refer to your mobile phone's user's manual for further information.
- When the volume is adjusted to max or min., you will hear one prompt tone.
- If you want to remote control last/next song, pause/play, it needs your Bluetooth mobile phone or Bluetooth transmitter paired with the headset to support AVRCP profile, please refer to the user's manual of your mobile phone or Bluetooth transmitter for further information.
- Only the paired Bluetooth devices(phone or transmitter) support "fast forward/fast rewind" function, and the headset can use this function. Please refer to your Bluetooth devices'(phone or transmitter) user's manual for further information
- The Bluetooth will disconnect between headset and mobile phone automatically if you plug 3.5mm audio input, and the Line in is available in this time, but the other functions of headset is not available.

6. LED indicator

1) Charging

LED indicator	Status of headset
Red LED on	Charging
Blue LED on	Finish charging

2) Pairing with Bluetooth device

LED indicator	Status of headset
Red and blue LED flashes	Pairing mode
alternately	
Blue LED flashes once quickly	Not connect device
every 2 seconds	
Blue LED flashes twice quickly	Have already connected device
every 4 seconds	-
Blue LED flashes slowly	Calling/incoming call
continuously	
Blue LED flashes once quickly	During a call
every 4 seconds	
Red LED flashes instead of blue	Low battery
LED	-

7. Indication tone

Indication tone	Status of the headset
Continuous two prompt tone	Conversation mode and
every 10 seconds	microphone mute
Three "dong" warning tone every	Low battery
30 seconds	-

8. Factory Reset

In the status of standby mode and not connect with device, long press MFB and bll button for 3~4 seconds simultaneously and release it until the red and blue LED on simultaneously.

Remarks:

- ◆ For factory reset, you should press MFB button first, and then press button or press MFB and bll button simultaneously.
- After factory reset, the paired list of headset will be deleted. When you turn on the headset again, it will enter paired mode automatically, but it won't connect with device automatically, you should re-pair and connect with devices.

■ Care and maintenance

Read the following recommendations carefully before using BTH033-KMA26. Following these you will be able to enjoy this product for many years.

- Keep it dry and don't put it in the dump place to avoid the product's internal circuit being affected.
- Keep the product away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't use this product during sport to avoid the sweat into product so that damage the product. This product is not water-resistant.
- Don't expose the product to cold areas. It may damage the internal circuit board.
- Don't try to disassemble the product as it may get damaged if you are not professional.
- Don't let it fall down onto the floor or other hard surfaces. The internal circuit might get damaged.
- Don't use intensive chemical products or detergent to clean the product.
- Don't scratch the surface with sharp things.

In case the product doesn't function properly, send it to the store you bought it. The staff will help you to solve the problem

■ FAQs

 What does it mean if all the LED indicator turns red? Battery is low power, need to be recharged.

2. Why is the red LED off when charging?

- a) Please make sure the charging device connect with headset Well;
- b) You didn't use the headset for a long time, the battery may dry up. At this time, you have to charge the battery for 30 minutes, and then the red LED will be ON.

3. How far is the effective rang between the headset and mobile phone?

According to the Bluetooth standard, the max available range of ClassII headset is 10 meters. It varies under different environment.

4. Why my mobile phone can not search and find the headset?

The mobile phone will not find the headset if headset and mobile phone are not under the pairing mode. Make sure the headset is under the pairing mode and in the effective working range, and then the headset can be paired and connected.

5. Why the headset can not hear the voice?

- a) Make sure the headset has been switched on:
- b) Make sure the volume is not too low or muted;
- c) Make sure the headset connects with the mobile phone correctly;
- d) Make sure the distance between the headset and the cell phone is in the available Bluetooth range.

6. Why the headset can not hear the voice clearly in conversation?

- a) Make sure the mobile phone is in the strong signal area;
- b) Make sure the headset is in the available range of this product.

7. Why can't control pause, play, last song and next song when playing music?

This function needs your Bluetooth device supports AVRCP (Audio/Video Remote Control profile)

■ Specifications

Bluetooth version	Bluetooth V4.0
Bluetooth profiles	Headset, Hands free, A2DP, AVRCP
Operating distance	10meters
Headset working time	Music up to 16 hours
Headset standby time	Approx 450 hours
Charging input	DC5.0V === 500mA
Headset charging time	About 3 hours
Dimension	176*165*32mm
Operating temperature	0 ~ 40 ℃
Weight	Approx 172.8g
Battery capacity	430mAH

Notes:

- 1.This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Due to the used enclosure material, the device shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Excessive sound pressure from earphones and headphones can cause hearing loss.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.