

# User Manual

Model No.:DS-988



## Listening to your iPod/iPhone/MP3

- 1.. Plug the AC adaptor into the DC in port at the rear of the base , then into a power supply. And put the battery into the compartment of the speaker.
- 2.Connect 3.5mm audio cable which located on the base to the audio output port of an auxiliary audio device (iPod /MP3,PC,CD player,etc)
- 3.Press both of the power button on the base and speaker to turn the unit on.
- 4.Press MP3 button on the speaker to turn to the audio mode.
- 5..Press corresponding“ channel” button1/2/3 both on the top of the base and right hand of the speaker until it receives the right signal.  
Noted:The unit would default to be channel 1 when at the beginning.
4. Use “VOLUME+” or “VOLUME-” on the right hand of the unit to adjust to a proper volume level,
- 5.Press the PLAY/PAUSE button on your iPod/iPhone to playback,press again to pause play.

## Charging for the battery

1. Put recharging battery into the compartment of the base.Make sure it fit the two charging contact points well.Then the indicator turned to be green to show the status of charging and turned to be red when full charged.

Noted:The indicator will be only on when the battery have been put into the recharging area of the base.

## Using LED clock

Press the button on the bottom of the speaker to turn the LED on and after 3 seconds will auto off.

Setting clock time

1. Press hour button on the right hand of the speaker,hour digits will begin flashing,Press the hour button again to adjust your desired hour and after 5 seconds the display will stop flashing to indicate the hour is set.
2. Press minute button on the right hand of the speaker,minute digits will begin flashing,Press the minute button again to adjust your desired minute and after 5 seconds the display will stop flashing to indicate the minute is set.

#### Using shelf inside the speaker

Push the mirror to open the door and then you store your razors and etc.

#### Radio operation:

1. Press the radio button to turn to the radio mode.
2. To press the STATION+ or STATION- button for 2 seconds,the unit will automatically scan and store radio station.
3. To press the STATION+ or STATION- button to tune the radio station.

#### FCC NOTE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference,and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC NOTE

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.