

# Instruction Manual and Warranty Information

HX-P200

HX-P200: The ultimate wireless speaker! Thank you for purchasing the HX-P200 wireless speaker for smartphones, tablets, notebook computers and other Bluetooth enabled devices.

## **Package Contents**



Jser Manual



Charging Cord


Speaker

## Charging the Unit

Approximately 2 hours required for full charge. Can be charged by using the USB to Micro USB cord (included) through computer or AC adapter with USB jack (not included). Note: Battery will last up to 4 hours when connected wirelessly and up to 12 hours when connected through Aux-In Audio Jack.


#### Controls

- Power Switch
- 2 Play/Pause Button 3 Volume Controls
- 4 Bluetooth Indicator
- 5 Line-In Audio Jack 6 **Charging Port**
- Battery Status Indicator
  - Forware/Reverse



#### Indicators

	Indicator	Status
CHARGE	Solid RED	Power ON
		Charging
	OFF (when charging)	Fully Charged
BLUETOOTH	Quick Flash BLUE	Pairing Mode
	Slow Flash BLUE	Paired
	Solid RED	Line-in Mode



## Listening to your device wirelessly over Bluetooth®

To listen to your music over Bluetooth wireless connection, you need to pair your device with HX-P200:

- device with HX-P2UU:

  1. Make sure your device has Bluetooth capability.

  2. Slide POWER SWITCH to turn on the unit, indicator will begin to flash.

  3. Follow the instructions of your device to pair the unit.

  4. Pair your device with the unit by selecting HX-P200 from your Bluetooth listings on your device or selecting YES. If prompted, then you will listen the paired successful prompt sound successful prompt sound.

  5. Press play on your device and use controls on the unit to adjust desired volume.
- NOTE: Once you have successfully paired your device, you typically will not need to repeat the above steps. Please ensure the unit source is set to Bluetooth and your device has Bluetooth enabled.

NOTE: When pairing with a computer running windows 7 OS, please consult your computer manufacturer for Bluetooth pairing instructions and/or Bluetooth Drivers.

# Listening to your device through the Auxiliary Line-In Audio Jack

- Connect Aux-in cable to the headphone or line-out jack of an audio device and plug the other end of the cable into the Line-In Audio Jack on the back of the unit.
- 2. Slide the POWER SWITCH to turn on the unit.
- Press PLAY on the device and use controls on the unit to adjust desired volume.

# FCC Disclaimer:

Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### One Year Limited Warranty:

For detailed Warranty Instructions and Information visit: www.homedics.com/audio-and-electronics/portable-audio/jam.html To obtain warranty service on your HMDX product, contact a Consumer Relations Representative by telephone at 1-800-466-3342 or email cservice@hmdxaudio.com for assistance. Please make sure to have the model number of the product available. Representatives are available 8:30am - 7:00pm EST Monday-Friday.