

| | |
|---------------------------------------|---------|
| Maytronics Remote Control Unit | 1 - 4 |
| Télécommande, Maytronics | 5 - 8 |
| Telecomando Maytronics | 9 - 12 |
| Maytronics Unidad de Control Remoto | 13 - 16 |
| Maytronics Fernbedienungseinheit | 17 - 20 |
| Maytronics afstandsbediening | 21 - 24 |
| Maytronics Unidade de Controlo Remoto | 25 - 28 |
| Пульт Дистанционного Управления | 29 - 32 |



maytronics

Maytronics 2010 Remote Control Unit



FCC statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance (Maytronics Ltd.) could void the user's authority to operate the equipment.


The 2010 Remote Control Unit (RCU)

The RCU offers two operation modes - Automatic mode and Manual direction control mode.

In Automatic mode, all cleaning parameters can be changed.

In Manual direction mode, the Pool Cleaner direction can be controlled manually.














The Control Panel of the Remote Control Unit



Setting the Automatic Mode

To Change the Automatic Mode settings



First press the Manual/Automatic select button, then set according to the following table:

| | | | | |
|--|--|--|--|---|
|  <p>Cleaning cycle indicator This determines the cleaning cycle time. The RCU allows you to choose between the following options.</p> |  <p>Fast</p> |  <p>Efficient (Default setting)</p> |  <p>Extra</p> | |
| <p>Supreme/Pulit</p> | <p>1.5 hour cycle</p> | <p>2.5 hour cycle for everyday use</p> | <p>3.5 hour cycle</p> | |
| <p>Residential cleaners</p> | <p>2 hour cycle</p> | <p>3 hour cycle for everyday use</p> | <p>4 hour cycle</p> | |
| <p>Commercial cleaners</p> | <p>4 hour cycle</p> | <p>6 hour cycle for everyday use</p> | <p>8 hour cycle</p> | |
|  <p>Delay Time indicator This determines when the pool cleaner starts to work. A delay allows the dirt to settle to the bottom of the pool.</p> |  <p>Immediate start (Default setting)</p> |  <p>One Hour delay</p> |  <p>Two Hours delay</p> | |
|  <p>Cleaning action indicator Allowing you to choose from the following options.</p> |  <p>Standard Floor and wall cleaning. (Default setting)</p> |  <p>Ultra-clean Stronger suction and slower movement Floor and cove cleaning only.</p> |  <p>Floor only Cleans only the floor and coves.</p> |  <p>Walls Only Cleans walls and waterline only.</p> |





Note:

- After 2 minutes, if no button is pressed, the Remote Control Unit will shut-down and the Pool cleaner will continue to work in the previous settings
- When the "Ultra-Clean" and "Walls Only" options finish their cycles, the RCU will return to default settings.

Manual Direction Control Mode

| | | |
|--|--|--|
|  <p>On/Off button</p> | <ol style="list-style-type: none">1. Press the ON/OFF button once - The RCU will start-up in Manual Direction control mode2. To manually control the direction of the cleaner, utilise the Direction control arrows (see right) |  <p>Direction control arrows</p> |
|--|--|--|

Exiting Manual Direction Control Mode and set the Automatic Mode

| | | |
|--|---|---|
|  <p>Manual/Automatic Select button</p> | <ol style="list-style-type: none">1. To exit the Manual direction control mode press the Manual/Automatic Selection button ONCE only2. The Digital screen will light up and three rows of function icons will show in default mode |  |
|  <p>Direction control arrows</p> | <ol style="list-style-type: none">1. To change the parameters press the up or down arrows. To choose the parameter settings use the right or left arrows.2. When you reach the required function press the Set/OK button |  <p>Set/OK button</p> |