

No. 60045

SIDE WINDERZ


Full Function Radio Control



WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years

CE 1797

8+
AGES



BATTERY CAUTION :

1. Alkaline battery is recommended.
2. Non-rechargeable batteries are not to be recharged.
3. Rechargeable batteries are to be removed from the toy before being charged.
4. Rechargeable batteries are only to be charged under adult supervision.
5. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
6. Do not mix old and new batteries.
7. Only batteries of the same or equivalent types as recommended are to be used.
8. Batteries are to be inserted with the correct polarity.
9. The supply terminal are not to be short-circuited.
10. If batteries are loose, bend out the contacts for a tighter fit.
11. Exhausted batteries are to be removed from the toy and be disposed of immediately: never dispose of batteries in fire.
12. If storing product for long periods of time, make sure to remove batteries.
13. Check the product periodically for signs of damage to electrical parts; do not play with product until damage has been properly assessed.

If the unit malfunctions, please remove the batteries for one minute and reinstall again.
If the malfunctions persist, please replace with new batteries.
BATTERIES SHOULD BE INSTALLED BY ADULTS ONLY.

Not suitable for children under three years. Risk of choking due to small parts that may be swallowed!
Please observe the instructions for use inside the package. Please keep this packaging information for any possible correspondence.
Subject to technical change and change of color. Adult help is required to remove the securing devices.

Side Winderz	Transmitter	
		 Don't Put In Trash. Recycle or Dispose as Hazardous Waste.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CONTENT




Transmitter x 1 pc
Side Winderz x 1 pc

BATTERY INSTALLATION



Battery Installation - Vehicle

1. Make sure the power switch is on OFF position.
2. Use a screwdriver to loosen the screw on the battery case anti-clockwise.
3. Open the battery door and pull out the battery compartment.
4. Put 6 x AA batteries in the battery compartment as per the polarities shown inside.
5. Put back the battery compartment in right position.
6. Close the battery door and tighten the screw clockwise.



Battery Installation - Transmitter

1. Make sure the power switch is on OFF position.
2. Open the battery by pushing to the right as shown.
3. Put the 9V battery door in the battery compartment as per the polarity shown inside.
4. Close the battery door.




1 x 9 V / 6F22 Battery
(Not Included)



Illustration

Transmitter



1. Operating lever (Forwards / Backwards)
2. Power Light
3. ON / OFF Switch



Functions

Forward, Backward, Turn Left, Turn Right, Spin, Stunt.

HOW TO PLAY




Switch On

1. To avoid accidental operation, the transmitter must be switched on before the vehicle.
2. When switching off, always switch the vehicle off and then the transmitter.



Spectacular Spins

To spin the Side Winderz 360°, run the car and push up the Right joystick and simultaneously push down the Left joystick, or push up the Left joystick and simultaneously push down the Right joystick depending on the chosen spin direction.



Awesome Cornering

To take extremely sharp turns or maneuver a 180° or 360° turn, run the car and push the Right and the Left joystick, then release the Right or the Left joystick to steer left or right.



Wild Wheelie

To make a wheelie, run the car and push both joysticks forward. The car will stand up on two wheels. Release slowly the Right or the Left joystick to steer.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply within the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generated, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harm to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment in to an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Colors & contents may vary. Please keep this packaging for future reference. Conforms to the safety requirements of ASTM F963.



©2010 PLAYMIND LTD.
Room 413-415, Houston Centre,
63 Mody Road, Tsim Sha Tsui East,
Kowloon, Hong Kong
Email : info@playmindltd.com
Visit us at : www.playmindltd.com

Made in China