

**maxell**  **Bluetooth®**  
*Mini*  
True Wireless Earbuds



TW MINI-WHT  
FCC ID: WKA-TW185B

USERS MANUAL **EN**  
MANUAL DE USUARIO **FR**  
MANUAL DE USUARIO **ES**

EN

**Specification:**

Battery capacity: Earbuds - (60mAh) Case - (400mAh)
Working Voltage and Ampere: 3.7V- 10mA
Earbud: fully charge for 50 minutes
Charging Case: fully charge for 2 hours
Play/Call Time : about <b>6 hours</b> for earbuds and <b>24 hours</b> with charging case
Driver Size : 10mm
Sensitivity : 98dB+/-3dB
Impedance : 16 Ohms
Bluetooth Version : 5.0 (Distance 10 meters)

**Charging case:**



EN

**Charging the case:**

To charge the case plug in the type c cord and connect into a computer or wall charger. When fully charged the battery life indicator will read 100% (takes about 1.5-2 hours).

**Charging the earbuds:**

Place the earbuds in the charger. The earbud LEDs will be a solid red when charging. The LEDs will turn off when they are fully charged (takes about 50 minutes - 1 hour).

**The function instructions:**



**1) Power on**

The earbuds will automatically turn on, once removed from the case.

**2) Power off**

Earbuds will automatically turn off, once you put them back into the case.

EN

**3) Pairing a new device:**

Remove the earbuds from the case, then place earbuds back into the case. Remove again this will automatically turn the earbuds on. The flashing red and blue LEDs indicate that you are now in pairing mode. You will hear a voice prompt saying "Pairing". Now go to your Bluetooth device list and select "TW MINI EB" to get connected. You will hear another voice prompt saying "Connected."  
No need to pair again, your Bluetooth device will automatically connect to the earbuds during future use.

**4) Earbud controls:**

**Pause/Play Music:** Short press the power button on either bud once.

**Volume +:** Long press the power button on the Left Bud for 2 seconds.

**Volume -:** Long press the power button on the Right Bud for 2 seconds.

**New Track:** Double press the power button on the Right Bud.

**Previous Track:** Double press the power button on Left Bud.

**Take and End call:** Press the power button on either bud once.

**Reject a Call:** Press the power button on either bud twice. Once rejected your music will automatically resume.

**5) Solo**

You can use either bud separate in solo mode, just in case you want to hear and be aware of your surroundings (ex: while driving). Just place either earbud back into the case and that earbud will turn off. The other earbud will remain on.

**WARRANTY INFORMATION:**

Maxell warrants this product to be free from all defects for a period of 90 days from the date of original purchase. This Warranty does not apply to normal wear or damage due to accident, abnormal use, misuse or neglect. This Warranty only applies to personal and individual use of the product and not for commercial, institutional or any other use. Any defective item will be replaced, at no charge, upon reasonable confirmation by Maxell of its defective condition, if returned with proof of purchase to an authorized Maxell dealer or directly to Maxell Warranty Replacement, 3 Garret Mountain Plaza, Suite 300, Woodland Park, New Jersey 07424. Neither Maxell nor any authorized Maxell dealer shall be liable for consequential damages arising from this Warranty, unless otherwise provided by law.

Maxell garantit que ce produit exempt de tout défaut pendant une période de 90 jours à compter de la date d'achat d'origine. Cette garantie ne s'applique pas à l'usure normale ni aux dommages dus à un accident, à une utilisation anormale, à une mauvaise utilisation ou à une négligence. Cette garantie s'applique uniquement à une utilisation personnelle et individuelle du produit et non à une utilisation commerciale, institutionnelle ou autre. Tout article défectueux sera remplacé, sans frais, sur confirmation raisonnable par Maxell de son état défectueux, s'il est renvoyé avec la preuve d'achat à un revendeur Maxell agréé ou directement à Maxell New Jersey 07424. Ni Maxell ni aucun revendeur Maxell agréé ne pourront être tenus pour responsables des dommages résultant de cette garantie, sauf disposition contraire de la loi.

Maxell garantiza que este producto está libre de defectos por un periodo de 90 días a partir de la fecha de compra original. Esta garantía no se aplica al desgaste o daño normal debido a un accidente, uso anormal, mal uso o negligencia. Esta garantía solo se aplica al uso personal e individual del producto y no al uso comercial, institucional o de otro tipo. Cualquier artículo defectuoso será reemplazado, sin cargo, luego de que Maxell confirme razonablemente su condición defectuosa, si se devuelve con el comprobante de compra a un distribuidor autorizado de Maxell o directamente a un reemplazo de la garantía de Maxell, 3 Garret Mountain Plaza, Suite 300, Woodland Park, New Jersey 07424. Ni Maxell ni ningún distribuidor autorizado de Maxell serán responsables de los daños consecuentes derivados de esta Garantía, a menos que la ley disponga lo contrario.

**FCC INFORMATION:**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.