


Control Different Control Methods - You may control the NEO X8 with the following input devices: 1) Remote Control App: for Android smartphones and tablets, more information can be found at www.minix.com.hk 2) Wired mouse: 3) 2.4GHz USB wireless mouse and keyboard set: 4) 2.4GHz USB air-mouse / gyro-mouse (MINIX branded mouses sold separately). 5) MINIX IR-Remote (included). Using the MINIX IR-Remote - Use the MINIX IR-Remote to control the NEO X8 settings and navigate your content. Make sure there are no obstructions between the MINIX IR-Remote and the NEO X8.  MINIX IR-Remote Functions MENU Call up the options menu for your current screen or running application HOME Return to the Home Screen (choice of launcher required) POWER To wake up from sleep or put the MINIX NEO X8 into sleep mode BACK Return to the previous screen/setting or to cancel an activity VOLUME DOWN Adjust the system volume down VOLUME UP Adjust the system volume up UP Move forward LEFT Move left RIGHT Move right DOWN Move backward OK To confirm a particular action and/or an "Enter" key	IR-Remote Functions What you need: High-Definition TV or PC monitor - That can display 270p, 1080p or 4K video with at least one HDMI input. HDMI Cable - To connect the NEO X8 to your TV (HDMI cable included). Wireless Network - A wired network cable or an 802.11 a, b, g, or n Wi-Fi wireless network (wireless video streaming requires 802.11g or n), your wireless network name and password. Software and accounts - To play content (videos, photos, music) from a smartphone or PC on the NEO X8 you will need: - A UHF/DLNA software pre-installed on your smartphone or PC. - A Google account to sign-in to Google Play Store to download the corresponding applications (e.g. Webshare, a network media center) necessary for streaming the content from a smartphone or PC. - Other accounts may be required for full access to some internet contents.	Basic Setup The MINIX NEO X8 connects to your TV or PC monitor through an HDMI port that deliver both audio and video. Before you set up the NEO X8, connect the ports on the side/back of your TV or PC monitor to ensure you have the right cable: - HDMI cable: You can connect the NEO X8 to a HDTV or home theater receiver that has a HDMI port, using the HDMI cable for video and audio. Step 1: Connecting the cable 1. Connect one end of the HDMI cable to the HDMI port of your TV / PC monitor. 2. Connect the other end of the cable to the HDMI port of the NEO X8. Step 2: Connecting the power - Connect the SV power adapter supplied in the package to the relevant port. - Press and hold the power button for 2-3 seconds to power on the NEO X8, the blue power LED should then glow. Step 3: Turn on your TV or PC monitor and select the corresponding HDMI port - Simply turn on your TV or PC monitor and select the corresponding HDMI port to confirm a particular action and/or an "Enter" key	Basic Setup Language Setup You may select the desired system language by following these steps: Launcher Home Screen > Settings > Language & Input > Language The default language is English, you may choose your desired language and confirm. Time Setup You should adjust the time zone according to your current location by the following steps: Launcher Home Screen > Settings > Date & Time > Select Time Zone Choose your time zone and confirm. Wi-Fi Setup (basic) To connect to your wireless network follow these steps: Launcher Home Screen > Settings > Wi-Fi > Check the option "To see available networks turn Wi-Fi on" Wi-Fi will turn on and automatically scan the wireless networks available, then select the wireless network that you wish to connect to and confirm. Key in the password of the Wi-Fi network when the virtual keyboard prompts, finally hit the "Connect" button.	Google Play Store Sign-in to Google Account. Launch the Google Play Store by the following steps: Launcher Home Screen > Google Play Store, select and confirm. To use the Google Play Store you will need a Google Account. If you already have a Google Account, select "Sign in" and login with your Google Account. If you don't have a Google Account yet, select "Get a Google Account" and complete the rest of the process. Upon completion of the sign in process you will be brought to the Google Play Store, allowing you to download and install the applications you want. Alternatively, if you cannot find the application you need on the Google Play Store because of language restriction, location restriction or other reasons: you may look for and then download the application file in the form of ".apk" from the internet and install them directly to your NEO X8. The application, which is pre-installed in the password of the Wi-Fi network when the virtual keyboard prompts, finally hit the "Connect" button.	XBMC XBMC is a media player that allows users to play and view most videos, music, such as podcasts from the internet, and all common digital media files from local and network storage media. The NEO X8 comes pre-installed with XBMC MINIX Edition, with full hardware decoding support. This exclusive edition delivers the optimum XBMC experience on Android. For more information and instructions regarding setup please visit: www.wiki.xbmc.org The content of this guide may differ in some details from the product or software. All information in this document is subject to change without notice. For online help and support, please visit www.minix.com.hk or join our facebook fanpage at: www.facebook.com/minixhk CE FCC RoHS Copyright © 2013 MINIX Tech. All rights reserved. FCC Warning This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be located or operated in conjunction with any other antenna or transmitter. *To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. Applicant: J&W Technology Limited Address: 13/F, Building 8, Hsiaocong Office, Sarnan Rd., Futian District, Shenzhen, China Tel: 86-755-23981883 Fax: 86-755-23981883
--	--	---	--	--	---