

Operation description

Applicant: Americhip Inc.

Product: Remote Control GiftCard

Model: 8067741

Frequency: 27.145MHZ

- 1、 Move power switch to “NO” position on Mouse Cart and Cheese Controller.
- 2、 Place Mouer Cart on flat,smooth surface.
- 3、 Pull antenna to extend range on the Cheese Controller.
- 4、 Push “Forward” button on controller to move the car forward.Push “Reverse(and turn)” button to move the car backward.Car also turns while moving backward.
- 5、 Radio control broadcast range:36ft.
- 6、 Be sure to turn both units “OFF” when not in use.