

Operation description

First of all, put 2 AAA 1.5v battery in the 2.4G wireless mouse and Keyboard , power on pc .waiting for the 2.4G wireless mouse and keyboard connect to PC,then you can move and press mouse and using keyboard .