

## Connection

### 1. To connect Cable Antenna

Connect the antenna cable to ANTENNA.

### 2. To connect Terrestrial Antenna

Connect the terrestrial antenna cable to ANT IN.

### 3. To connect TV / VCR

Connect RCA, SCART, or S-VIDEO cable to the receiver.

### 4. To connect Digital Audio System

Connect S/PDIF coaxial cable to a digital amplifier.

### 5. Loop Through

Connect coaxial cable to the Loop Through on the STB and connect the other STB.

## Menu Application

Press the **MENU** button on the remote control unit. You will see the **Main Menu** on the screen.

1. Press the ▲/▼/◀/▶ buttons to move to sub menu.
2. Press the **OK** button to select or confirm menu.
3. Press the **MENU** button to return to previous menu.
4. Press the **EXIT** button to quit the menu.

## Easy Installation

You will see only **Easy Installation** menu at first when you plug in your system.

The Easy Installation gives you the convenience of selecting various languages, adjusting the time and channel search.

### 1. Language

The Language of Menu, Audio, or Subtitle will be changed to the selected language.

### 2. Local Time

You can set your local time according to your location.

### 3. Channel Search

You can search the channels according to the Automatic or Manual mode.

### 4. Channel Search

#### • **Manual Search**



→ Input a proper Frequency of the cable signal using **NUMERIC** buttons.

→ Input a proper Symbol Rate of the cable signal using **NUMERIC** buttons.

→ Select the Constellation (AUTO, 16, 32, 64, 128 or 256 QAM) using ◀/▶ buttons.

→ Select the spectral Invert (Auto, Off or On)

→ Select for the Network Search(Off or On). When you select



"**On**", you can find more services using the home network.

→ Press **OK** button.

→ When searching is started, the name of channels searched will be displayed on the screen.

→ When searching is finished, the "**Search finished**" message will be displayed on the center of the screen.

→ Press the **OK** button to save the channel list and watch the channel searched.

#### • **Automatic Search**

→ Input a proper Start Frequency of the cable signal using **NUMERIC** buttons.

→ Input a proper End Frequency of the cable signal using **NUMERIC** buttons.

→ Input a proper Symbol Rate of the cable signal using **NUMERIC** buttons.

→ Select the Constellation(AUTO, 16, 32, 64, 128 or 256 QAM) using **◀/▶** buttons.

→ Press **OK** button.

→ When searching is started, the name of channels searched will be displayed on the screen.

→ When searching is finished, the "**Search finished**" message will be displayed on the center of the screen.

→ Press the **OK** button to save the channel list and watch the channel searched.

## Menu Guide

### 1. Program Information Banner

After the television channels have been programmed, you will see the information box each time you change the channels.



#### Note

If you press the button below, the banner will be displayed like the following.

1. **GREEN** button → **Now** information banner.
2. **YELLOW** button → **Next** information banner.
3. **INFO** button → **Channel** information banner.

### 2. Teletext / Subtitle

Press the **RED** button to select the **Subtitle** or **Teletext**, then you can see the subtitle language.

### 3. Once, Daily, Weekly Reservation *The user can reserve a desired program at a desired time by using the Timer function.*

Pressing the **YELLOW** button to use the **▲/▼/◀/▶** buttons in the **Timer Setting** screen to select the date and time.

### 4. Simple Channel List

1. When you press **OK** button during receiving service stream, you can get **Channel List** view.

2. Using **▲/▼** buttons in **Channel List** view, you can choose another channel.

## Channel List

This menu helps you to easily select the channel that you want to watch.

You can see the channel list when you had searched before.

To use this menu, you should set channel group you want in the ***Edit Channel List*** menu.

1. To see the available channel list, use the ***SUB-T***(Red) button. The channel list moves in the following sequence : ***ALL*** → ***Favorite*** from ***1*** to ***4*** → ***Lock***