











Test Configuration Photos

Test positions for Head:

Cheek device with left head phantom	Tilt device with left head phantom
	
EUT Setup Configuration C-1	EUT Setup Configuration C-2
Cheek device with right head phantom	Tilt device with right head phantom
	
EUT Setup Configuration C-3	EUT Setup Configuration C-4

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =10mm between the EUT and the phantom bottom:

Front in body position	Back in body position
	
EUT Setup Configuration C-5	EUT Setup Configuration C-6
Left Side in body position	Right Side in body position
	
EUT Setup Configuration C-7	EUT Setup Configuration C-8
Top Side in body position	Bottom Side in body position
	
EUT Setup Configuration C-9	EUT Setup Configuration C-10