

## Test positions for body:

According to the antenna position, the Body SAR is tested at the following 3 test positions all with the distance =15mm between the EUT and the phantom bottom:

Phantom close in body position	Ground closein body position
EUT Setup Configuration 5	EUT Setup Configuration 6
Ground Open Side in body position	N/A
	N/A