


# M50 FAST OPERATION MANUAL



## 1. Power On-Off

Power on: Press any key to turn on.

Power off: Power off automatically based on the system off time, if there is no press and voting; or power off remotely by software.

Indicator Led: After power-on and channel locked, the green light flash every half second; if lost channel, the red light flash slowly; if low battery, green light flash every two seconds; starting voting, the green light quick flash 4 times within every second;after effective key pressing, 2 times with every second;after voting submitted successfully,led stay green.

## 2. Function

Polling types	Operation
● Sign-in	Press “OK” or “1” to sign in
● Vote	“1.2.3” stand for “Yes, No, Abstain” separately. The answer will be submitted automatically based on the system settings.
● Single choice	Support max. 10 options. Make the single choice by pressing 1~9 (0 stands for 10) The answer will be submitted automatically based on the system settings or pressing OK to submit If changing the choice, please press the new choice directly.
● Multiple choice	Support max. 10 options. Make the multiple choices by pressing 1~9 (0 stands for 10), after the choices number reaching the set value, adding choices will not be accepted. If changing the choice, please press C key to clear, and then input the new choices and press “OK” to submit. After submit successfully, if changing is allowed, re-input directly. If under forced choice mode, submit can be successful only after

	selecting enough options.
● Sequence	As Above But, if repeated choices are allowed, an option can be input repeatedly.
● Score	Input max. continuously 3 numbers Press “C” key to cancel the previous number.
● Fastest answer	Press “OK” or “1” to be the first answerer.

### 3. Match up

Before using together with the base station, new keypads should be matched up with the base stations.

Firstly make the base station entering into match-up mode by operating the software, secondly press “OK” and “C” till the indicator lamp red and green flash alternating , finally if the green light indicates channel locked, it stands match up successfully. Meanwhile the software will also indicate it.

If directly powered off, it stands match-up failure.

### 4. Parameter configure

Press “OK” together with base station and software to read or write keypads ID.

#### FCC Caution.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### RF warning:

The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.