




TONE FREQUENCY = 300Hz	
REF: 0dB ⇒ 60% deviation	
AUDIO LEVEL [dB]	DEVIATION [Hz]
-30	85
-24	46
-18	137
-12	213
-6	427
0	796
6	1545
12	2958
18	3986
24	3984
30	3986



TONE FREQUENCY = 1000Hz	
REF: 0dB ⇒ 60% deviation	
AUDIO LEVEL [dB]	DEVIATION [Hz]
-30	135
-24	230
-18	386
-12	825
-6	1482
0	3022
6	4060
12	4016
18	4001
24	4055
30	4094



TONE FREQUENCY = 2000Hz	
REF: 0dB ⇒ 60% deviation	
AUDIO LEVEL [dB]	DEVIATION [Hz]
-30	253
-24	407
-18	775
-12	1059
-6	2947
0	3849
6	3887
12	3980
18	3958
24	3897
30	3903



TONE FREQUENCY = 3000Hz	
REF: 0dB ⇒ 60% deviation	
AUDIO LEVEL [dB]	DEVIATION [Hz]
-30	232
-24	396
-18	838
-12	1403
-6	2707
0	2940
6	3004
12	3015
18	3889
24	3974
30	3952

