

RUNNER User Manual



EN Sport Bluetooth Headset Model:G15B

Preface

Dear Customer

Thank you for choosing Runner Sport Bluetooth Headset. Please read the user manual carefully for proper instruction to maximize the advantage of our product. Our Bluetooth headset are well designed, fashion, smart and portable, pure acoustic and multi functional. We have patents for the whole series of our Bluetooth headsets. Our Bluetooth headsets are applied with the top advanced electro acoustic technology, providing you the best enjoyment of music any time at home, outdoor or business work, and provide the perfect acoustic with your notebook and any digital audio/visual devices. Lead you to wonderful music, enjoy healthy & happy life.

Precautions / Tips

Cautions


- Please keep or use this product at normal temperature;
- Do not expose this product in rain or moisture;
- Do not throw this product in case any damage thus made;
- Do not disassemble, repair or reform this product;
- Do not clean this product with any chemical solvents;
- Please use USB power of DCSV for output when needed;
- Do not throw away or put it in fire to avoid any danger.

Product Description

Item: Runner Sport Bluetooth Headset
 Bluetooth standard: V4.1
 Charging means: power adapter output(DCSV 150mA)
 Battery:rechargeable lithium polymer battery
 Bluetooth Operation: class 2
 Talk time: up to 7 hours
 Playing time: up to 6 hours
 Stand by time: up to 200 hours
 Operating range:10m
 Compatibility of Bluetooth Device: Compatible with 99% mobile phones
 Battery Display: Battery Display on IOS Devices

- The Bluetooth headset can be applied to audio from any Bluetooth devices like mobile phones,notebooks.
- When being connected to Bluetooth DONGLE on PC,it can play any audio files on the computer.You can use it for voice chat to achieve wireless QQ,MSN,SKYPE.

Product Schematic



Features

- ⏻ Power on-Press and hold the "MFB" button for 1 second, and the blue indicator light flashes 3 times.
 Power off- press and hold the "MFB" button for 3 second,the red indicator light flashes once.
- 📞 Answering a call-Short press any button.
- 📞 Ending a call-Short press the "MFB" button when headset is in standby mode.
- 📞 Rejecting a call-Long press the "V-" button for 1 second.
- 📞 Redialing the last called number-Double press the "MFB" button when headset is in standby mode.
- 📞 Voice dialing-With the headset in standby mode, long press the "MFB" for 1 second and release (Your phone must support this function).
- 📞 Call transferring- During a call, long press the "V+" button for 1 second.
- ▶ Play / Pause-Short press the "MFB" button to play and pause when headset is in standby mode.
- ▶ Previous/Next Track-Press the "V-" 1 for second to previous track, press the "V+" 1 for second to next track.
- 🔊 Volume control: Volume will be up when short press the "V+" and will be down when short press the "V-".
- 🔇 Microphone muting: During a call, press "V-" again for about 1 second, microphone is muted; press "V+" again for about 1 second it will work again.

Handling of the Waste Electrical

The waste Electrical

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Features

- Important:**Different mobile phone brands or menu function, the usage will be different.Please read your phone's manual carefully.
- 🔊 Voice Prompt
 - When the headset is on, there will be the automatic voice prompt: power on
 - When the headset is off, there will be the automatic voice prompt: power off
 - When being connected successfully, there will be automatic voice prompt: your headset is connected
 - When being disconnected, there will be automatic voice prompt: your headset is disconnected
 - When the battery is low, there will be voice prompt: battery low
 - 📱 Pair to your Bluetooth Phone
 - Pair the bluetooth headset for the first time, the distance between the Bluetooth headset and your Bluetooth phone would be better within 1 meter when pairing.
 - With the headset power off, hold and press the "MFB" button for 3 seconds, red light and blue light flash alternately, then the headset enter the searching mode; lasts about 2 minutes.
 - When phone finds headset, confirm by selecting "Runner" from list. Enter pin code "0000" if needed.
 - Repeat above steps if the pairing was unsuccessful.
 - The blue light will flash if paired successfully.
 - 🔋 Power Alarm- There will be low power alarm when the voltage is lower than 3.3V.
 The headset will be power off when the voltage is lower than 3V.

Service Regulations and Explanation

After service

(A) Service system

- 1.Consultancies: Please read this user manual carefully before using this product. For any problem during using it, you can contact your seller.
- 2.Exchange service: within exchange time limit, for any indeliberate error during proper use, making sure the product as well as its accessories and package are all not damaged (if the appearance is damaged, it can only be repaired) you can either have it exchanged for a new one or repaired after the error is tested and examined;
- 3.Warranty service: within the warranty time limit, for any indeliberate error that occurs during proper use, warranty service is free for no charge (the headphone has warranty service for free within one year; for any deliberate damage, the warranty service should be paid).
- 4.Charged warranty service: within three years counting from one year after the date the product was purchased, any error repair will be charged; and user should pay the repair components, freight and labor cost.

Features

- 📱 Connect two Bluetooth mobile phones at the same time
 - After paired the first mobile phone, please turn off the Bluetooth function of the first mobile phone, then pair to the second Bluetooth mobile phone.
 - Active the first mobile phone Bluetooth function, manual connection the first mobile phone.
 - During a call, short press the "MFB", hang up the current call, then answer the incoming call.
 - Double press the "MFB" to answer another incoming call while you are on one phone call, and switch between the two incoming calls.
 - Short press the "MFB" to cut off the incoming calls by one.
- Note: While two mobile phones are connecting one Bluetooth headset, some functions of the Bluetooth headset will be restricted.
- 🔋 Charging the headset
 - Your headset uses a rechargeable battery, you must charge the battery fully before using the headset for the first time.
 - Plugging the charging cable in the USB charge port.
 - The red indicator lamp remains solid when charging. The fully charging takes 3 hours.
 - The red indicator lamp goes out and the blue indicator remains solid when charging completed.

5. Any of the below situation is not in the warranty service, but we provide charged service:

- ① The warranty date is expired;
- ② The warranty card is altered, or the series number differs from that of the product;
- ③ Accidental or deliberate damage is done to the product (for example: improper use against the user manual, improper set up which causes error, plugging in unmatched power, exposed to water, fallen etc.)
- ④ cannot provide valid warranty card or invoice (other but can prove that it is within the service limit);
- ⑤ Any error damage caused by force majeure such as earthquake, fire, flood, lightning strike etc.
- ⑥ Deliberate assembling, repair or reform without permission from our company.

(B) Explanation of After Service:

- 1.The date of purchased should be in accordance with that of the invoice, any failure to provide the valid proof, is subjected to the production date.
- 2.Quality problem does not include user's personal preference to tone and timbre.
- 3.The shell and user manual package are exclusive to warranty service.
- 4.For the model that production has been stopped, we only provide functional repair.
- 5.We are not responsible for any promises by retailer other than our company.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.