

Supplement to the User Guide

veriCLASS

VP3500 Reader Board P-Series Payment and Ticketing **Embedded Reader Platform Hardware Specification** PLT-02091, Rev.A.3 September 2014

This user guide is a draft version. It does not contain a note that the module "RFID-Dual-IVG " has to be used in combination with the external antenna, described in the document "Ext. Antenna Specification" (Doc. No. 7 001 020 103).

Doc. No. 7 001 020 104

The final version of the user guide will contain this note.

Bayreuth, 18. August 2014 / August 18, 2014

DESKO GmbH

Marchal &h

Harald Schmaus Research & Development D-95448 Bayreuth GERMANY