

WINPLUS NORTH AMERICA 375 West Apra Street Rancho Dominguez, CA 90220

Tel: 310-638-0588 Fax: 310-496-2740 Rancho Domingiuez, CA 902.201

Inti 4, Two Counties Estate, Facioner Road,
Tet. 441-440-71388

Havefilli, Suffolk CB9 7XZ, U.K.

Inti 2, 931 Mountain Havy Boronia,
Tet. 61-39720-4143

Victoria, Australia, 3155
Fac. 61-39720-4163

Fac. 64-9-5256517

Auckland, New Zealand
Fac. 64-9-5256517 EUROPE AUSTRALIA ASIA Suites 6-11, 7th Floor Corporation Park, 11 On Lai Street Shatin, N.T., Hong Kong Fax: 852-2798-8932

© 2008 Winplus North America Inc. All Rights Reserved. Winplus, the logo design, and yada are trademarks or registered trademarks of Winplus North America Inc. The Bluetooth* word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Winplus North America Inc. is under license.

yada **Bluetooth**®

YD-V16 User Manual

www.letsyada.com

WINPLUS

enjoy all features and benefits offered by the YD-V16 Bluetooth® Rearview Mirror Speakerphone. These features and benefits were designed with the goal of making wireless communication more convenient for the user Winplus USA 375 W. Apra St. Rancho Dominguez, CA 90220 info@winplususa.com info@winplususa.com www.winplususa.com

Thank you for purchasing the latest Yada wireless

technology product from Winplus. We hope you will

Winplus Europe Unit 4, Two Counties Estate, Falconer Road, Haverhill, Suffolk CB9 7XZ, UK info@winplus-europe.com www.winplus.net

Winplus Asia Suite 6-11, 7th Flr Corporation Park 11 On Lanai St., Shatin NT, Hong Kong info@winplus.net www.winplus.net

Winplus Australia Unit 2, 991 Mountain Hwy Boronia Victoria, Australie 3155 customercare@winplus.com.au www.winplus.com.au

Winplus New Zealand 22-24 Olive Road, Penro Aukland, New Zealand Griffiths Equipment web@griffiths.co.nz

1

www.types.co.nz

PACKAGE CONTENT INSTALLATION BATTERY OPERATIONS SPEAKERPHONE OPERATIONS **BUTTON FUNCTIONS**

CONTENTS

WARRANTY / LIABILITIES

DISCLAIMER

2

6

LCD DISPLAY INDICATION LED INDICATION CARE AND MAINTENANCE TROUBLE SHOOTING

CUSTOMER SERVICE / CONTACT US PAGE FCC/ICC

Distracted driving is dangerous. Always use the Bluetooth® Device in a manner that does not reduce your attention and ability to drive carefully and safely. Adhere to all applicable traffic laws and motor vehicle regulations applicable to the device.

DISCLAIMER

- to the device.

 Consult local laws and regulations for any restrictions on installation or use.

 Do not install on or near an airbag. Such installation could interfere with airbag deployment or could cause the product or another object to become a projectile, which could result in serious personal injury to occupants. Ensure the product location will not obstruct your vision while driving. Observe all signs that require an electrical device or RF radio product to be switched off in the designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.

 Never allow children to play with the device. Small nexts may be a cheking.
- Never allow children to play with the device. Small parts may be a choking nazard.
 Always practice safe driving habits.
 Ensure that the charging cable does not interfere with your line of site while driving when the device is being charge.
 Improper use and installation may cause severe injuries, make sure to follow
- installation instruction and safety procedure WARRANTY / LIABILITIES
- WINPLUS NORTH AMERICA LIMITED WARRANTY
 WINPLUS North America warrants, to the original purchaser, that its products are free from defects in material and workmanship for 90 days from the date of original purchase. Where permitted by law, WINPLUS North America's liability shall be limited to that set forth in this limited express warranty. This limited express warranty shall be the exclusive remedy of the purchaser and WINPLUS North America makes no other warranty of any kind aside from the limited express warranty stated above.

Note: Warranty only applies for North American customers or purchases made in the North America.

If it is necessary to return your product for service, please return it securely packed, preferably in the original shipping box, and freight and insurance prepaid to the following address:

ATIN: WINPLUS YADA BLUETOOTH® PRODUCTS RETURNS 375 W. Apra St.
Rancho Dominguez, CA 90220

Please include a detailed explanation of the problem you are having. If your product is found by WINPLUS North America to have a defect in material or workmanship, within the warranty period, it will be repaired or replaced at no charge and returned to you prepaid.

WINPLUS North America makes no other warranty of any kind aside from the limited express warranty stated herein.

DISCLAIMER OF WARRANTIES. INCLUDING WARRANTY OF MERCHANTABILITY AND WARRANTY OF FITNESS FOR PARTICULAR PURPOSE: EXCEPT AS SPECIFICALLY SET FORTH HEREIN, NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, IS MADE AS TO THE YD-V16 BLUETOOTH* REARVIEW MIRROR SPEAKERPHONE. EXCEPT AS EXPRESSLY SET FORTH HEREIN, WINPLUS NORTH AMERICA AND/OR ITS AFFILIATES EXPRESSLY DISCLAIMS, WITHOUT LIMITATION, ANY STATUTORY WARRANTIES AND ALL IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

WINPLUS North America and/or its affiliates are not responsible for a user's intended or actual use of the YD-V16 Bluetooth* Rearview Mirror Speakerphone. In no event shall WINPLUS North America and/or its affiliates have any liability for any losses (whether direct or indirect, in contract, tort or otherwise) incurred in connection with the YD-V16 Bluetooth* Rearview Mirror Speakerphone. Neither shall WINPLUS North America and/or its affiliates have any liability for any decision, action or inaction taken by any person in reliance on the YD-V16 Bluetooth* Rearview Mirror Speakerphone, or for any delays, inaccuracies and/or errors in connection with the YD-V16 Bluetooth* Rearview Mirror Speakerphone and its functioning. WINPLUS North America and/or its affiliates shall have no responsibility or liability for damage and/or injury resulting from accidents while user is utilizing the YD-V16 Bluetooth® Rearview Mirror Speakerphone; and WINPLUS North America and/or its affiliates, the manufacturer, distributor and seller shall not be liable for any injury, loss or damage, incidental or consequential, arising out of the use or intended use of the product.

WINPLUS EUROPE LIMITED WARRANTY

WINPLUS AUSTRALIA

Speakerphone:

Speakerphone

down modes.

charging in the vehicle unattended.

CONDITIONS OF WARRANTY

bill of sale.

The replacement of parts is excluded from the warranty when replaceme is necessary due to normal wear and tear.
Repair or replacement parts supplied by WINPLUS North America under this warrantly are protected only for the unexpired portion of the original warranty.

This is a "repair or replace" warranty only, and does not cover the costs incurred for the installation, removal or reinstallation of the product, or

The equipment must not have been altered or damaged through negligence, accident, improper operation, or failure to follow the product

charge for parts or labor subject to the following conditions:

1. All repairs must be performed by WINPLUS North America

instructions for installation, use, or care,

during the 90 day warranty period your new product is found to be defective, WINPLUS North America will repair such defect, or replace the product, without

All warranty claims must be accompanied by a copy of the sales receipt or

damage to any mobile phone devise or vehicle. OWNER'S RESPONSIBILITIES:

OWNER'S RESPONSIBILITIES:
WINPLUS North America will make every effort to provide warranty service within a reasonable period of time. SHOULD YOU HAVE ANY QUESTIONS ABOUT SERVICE RECEIVED OR IF YOU WOULD LIKE ASSISTANCE IN OBTAINING SERVICE, PLEASE CALL TOLL FREE 1.866.294.9244 DURING REGULAR BUSINESS HOURS MONDAY THROUGH FRIDAY 9:00 AM TO 5:00PM.

Note: Toll Free # is for North America Customers ONLY. See Customer service section for customer contact numbers for other regions/offices In order to provide you with the proper warranty service, we request that you adhere to the following procedure:

1. Include a copy of your sales receipt or bill of sale with your unit when it is

returned for warranty service

winVLUS warrants, to the original purchaser, that its products are free from defects in material and workmanship for 12 months from the date of original purchase. Where permitted by law, WINPLUS liability shall be limited to that set forth in this limited express warranty. This limited express warranty shall be the exclusive remedy of the purchaser and WINPLUS makes no other warranty of any kind aside from the limited express warranty stated above.

WINPLUS warrants, to the original purchaser, that its products are free from

OWNER'S RESPONSIBILITIES:

In order to provide you with the proper warranty service, we request that you adhere to the following procedure:

1. Include a copy of your sales receipt or bill of sale with your unit when it is returned for warranty service.

2. If it is necessary to return your product for service, please return it securely packed, preferably in the original shipping box, and freight and insurance prepaid to the following address:

ATTN: WINPLUS BLUETOOTH* PRODUCTS RETURNS

Unit 4, Two Counties Estate, Falconer Road ATM: WINPLUS BLUE FOOTH* PRODUCTS RETURNS
Unit 4, Two Counties Estate, Falconer Road
Haverhill, Suffolk CB9 7XZ, UK
Please include a detailed explanation of the problem you are having.
If your product is found by WINPLUS to have a defect in material or
workmanship, within the warranty period, it will be repaired or replaced at
no charge and returned to you prepaid.
WINPLUS makes no other warranty of any kind aside from the limited express
warranty stated herein.

WINPLUS AUSTRALIA LIMITED WARRANTY
This product is warranted against faulty workmanship for a period of 12 months from the date of purchase. Winplus' liability is limited to replacement of the product. Claims for associated or consequential loss or damage will not be accepted by Winplus. Product is not fitted, used or installed in accordance with instructions will not be eligible for warranty.
WINPLUS makes no other warranty of any kind aside from the limited express warranty stated herein.

Bluetooth® Rearview Mirror Speakerphone INSTALLATION

(PACKAGE CONTENT)

For added safety, use Velcro straps back of the mirror (see above image) Press Velcro straps together to secure Pull the tension clamp and clip to the existing rearview mirror Push the rearview mirror speakerphone until it is flushed against

Warning: Do not pull or remove the rearview mirror without pulling apart the

B. Low Battery Power Indicator When battery power is low, the device will: Flash red LED light Recharge the YD-V16 immediately after the low battery indicators are detected.

Connect the DC power jack to the YD-V16 Bluetooth® Rearview Mirror

BATTERY OPERATIONS

A. Charging the Battery Follow the steps below when charging the YD-V16 Bluetooth® Rearview Mirror Speakerphone

MPORTANT: Before using the YD-V16 Bluetooth® Rearview Mirror

Fully charge the battery (8 hours continuous) for first time use

Only use rechargeable batteries provided

Connect car charger to cigarette power outlet LED will flash red when charging is initiated Red LED will flash off when charging is complete /!\ IMPORTANT: Remove device from cigarette outlet before leaving the

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions. Note: Actual talk time and standby time for the YD-V16 will vary with different Bluetooth® enabled mobile phones due to different implementation of power

vehicle. Do not leave the YD-V16 Bluetooth® Rearview Mirror Speakerphone

A. Power on/off Press and hold the Power Switch Button ountil the LED flashes blue Release the button and wait for YD-V16

Phone Button

Power Switch Button

(end)

10

14

16

18

20

22

The YD-V16 will not power on until it is connected to a power outlet to recharge. Recharge the YD-V16 sufficiently before using. SPEAKERPHONE OPERATIONS

tension clamp


7

DC jack outlet USB outlet caller ID screen

The LED light will not turn on indicating battery power is completely consumed.

Follow "Charging The Batteries" instructions above to recharge the YD-V16.

volume up microphone send end



If no device was found, YD-V16 will stay on the screen To search again, press phone button () once to activate search mode Searching

To turn the YD-V16 off:

Note: Before automatic connection, please make sure Bluetooth® mode on your mobile phone is activated and you must have at least successfully paired and

to enter into search mode Searching

Device will stay in search mode for 5 seconds

connected to YD-V16 at least once in order to activate this feature.

about connecting Bluetooth® devices)

Phonebook Set-up via AT Command

Once it is connected:

YD-V16 will emit a b

Mirror Speakerphone.

Press and hold the Power Switch Button of for at least 5 seconds B. Pairing/Linking Pairing Bluetooth® enabled devices like mobile phones with the YD-V16 Bluetooth® Rearview Mirror Speakerphone authorizes the devices to work with each. This step only needs to be performed once.

Ensure the YD-V16 is fully charged Charging cable is disconnected You have the pairing instruction of your Bluetooth® wireless phone

Before Pairing the YD-V16 Bluetooth® Rearview Mirror Speakerphone:

To Link YD-V16 to your mobile phone after pairing: Pressing the SEND button ① of your YD-V16 or Establishing the connection via your mobile phone Note: Make sure Bluetooth® has been activated on your mobile phone before

you press the SEND button. (Please refer to your mobile's operation manual

The mobile's ID will be displayed on the screen (Ex. "Motorola V3")

AT Command and OPP (Object Push Profile) function can automatically

transfer the contacts in your mobile phone to the YD-V16 Rearview

Note: NOT ALL MOBILE PHONES SUPPORT AT Command and OPP Features

If found, phone display should indicate YD-V16 or Select "YD-V16" from the list Phone should give you a prompt asking if you want to pair the device Select OK or ACCEPT and wait for prompt to enter passkey or PIN Enter the code 0000 when a passkey is requested Select "OK" to pair the YD-V16 and the handset

When pairing is complete, the YD-V16's LCD will show PAIRING SUCCESSFUL $\,$ icon Pair OK $\textbf{Note:} \ \textbf{If the YD-V16} \ and \ mobile \ handset \ did \ not \ successfully \ pair, \ follow \ the \ steps$

Turn the phone off; wait for 10 seconds

Repeat the pairing instructions from the beginning

To transfer the Phone Book from your mobile phone via OPP:

Note: Please refer to your mobile phone's user manual

mobile phone to your YD-V16

To modify/delete speed dialing number:

D. LCD Display

• Press Menu

To cancel mute:

F. Call Operations Making a Call

Press Menu button again

Press **Menu** button

To call last number dialed:

Press Send button ①

5. Caller ID Display

a) By Name

17

19

To make a call using the phone book:

Press Send button (1) to enter

Press Send button (1) to enter

Press Send button 🕥 again to dial

Press Send button (1) again to dial

To call using the speed dialing function:

Caller ID can be displayed in 3 ways:

Press the + or - button until you see Contact list

Press the + or - button until you find the desired last dialed number

Press and hold the **Menu** button or the + or - button for 2 seconds

Note: Caller ID Display is a network service; please consult your network provider

YD-V16 can display the caller's name when receiving call. To display caller's

Phone will automatically dial the number set to Speed Dial for that particular button

Select name by pressing the + or - button

15

To adjust contrast of LCD Display:

Press Send button (1) to enter

To mute the YD-V16 during an active call:

Press Menu button for two seconds

you can save a new number for that slot/button

below to retry pairing:

11

13

Turn phone power on

2. Phonebook Set-up via OPP The YD-V16 supports single contact or group contacts transfer via OPP function. For details on operating procedures, please refer to your mobile phone's user

Disconnect Bluetooth® link from the YD-V16 setting (if it is connected)

Setup mobile phone for copying and transferring the contacts from the

To transfer the Phone Book from your mobile phone via AT Command: Make sure the YD-V16 and mobile phone is connected Press Menu Scroll the menu by pressing + or - button until you see Contact list

Press Menu button to enter Phonebook Transfer Inquire

Press Send button (a) to start or press End button (b) to end

LCD will display Downloading... to indicate Phonebook transfer is in process

Once transfer is successful, LCD will display Download Complete

LCD will display Yes or No? Press Send button (1) to confirm LCD will display Deleting Contact while phone book entries are being deleted LCD will display Deleted ALL when phone book is cleared Press End button to return to Main Menu

LCD will display Downloading to indicate contacts transfer is in process Once transfer is completed, LCD will show number of records transferred Reconnect the Bluetooth® link of your YD-V16 and mobile phone Note: Some mobile phones are able to register multiple phone numbers under

the same name. The YD-V16 phonebook can distinguish the numbers using the $\,$

letters: <M> for mobile phone number, <H> for home number and <O> for office

3. Deleting Phonebook entries: To delete Phone Book entry Press Menu Scroll the menu by pressing + or - button until you see Delete Contact Press Send button ()

To delete a number in a speed dialing entry Press Menu Scroll the menu by pressing + or - button until you see Quick Dial Search for the entry that you would like to modify

Scroll the menu by pressing 🛨 or 🗕 button until you see Contrast Setting

The status bar is shown in the contrast menu. This indicates the contrast level

Press Menu button twice and the screen will show Delete? Press Send button (1) to confirm or End button (2) to cancel

of the LCD display

Press the + or - button to adjust to desired contrast level

Press Send button ① to save setting

Once you have saved a number for a slot/button, you need to delete it before

Note: YD-V16 does not allow deleting of a single entry; ALL entries will be deleted after confirmation

+ , - button and the Menu button

Press the **Menu** button after finding an empty slot

Speed Dial Set-up

Note: Phonebook should be set up first to activate speed dialing. Press **Menu** Scroll the menu by pressing + or - button until you see Quick Dial Press Send button ()

Browse for an empty memory slot by pressing + or - button. There are

a total of 3 memory slots for speed dialing with each slot represented by the

Browse the phone number that you wish to set to speed dial Press Send button ① to confirm
Press End button to return to Main Menu Note: If a memory slot is empty, user can simply press the desired key for 2 seconds then follow the above procedures.

E. Volume Adjustments To adjust ring volume:

Press the + or - button to adjust ring volume To adjust call volume Press the + or - button to adjust the volume during a call

To adjust microphone volume during a call:

provider or the mobile phone itself.

Say the name after you hear the tone

2. Answering Calls

conversation is ongoing

Button

LCD Display YD-V16

Pair Mode Pair OK

Searching

NAME

NAME

Missed Call

Download Contact?

Downloading...

ownload Complete

Adjust the volume directly on the mobile phone Fine tune it using the volume control of the YD-V16

If you cannot hear the person you are talking to on the other line, do the following steps while conversation is in progress: $\frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2} \left(\frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2} \left$ Adjust the microphone volume of the YD-V16 to maximum level or Request the person on the other line to adjust his/her mobile phone's volume level to maximum If there is a strong echo when the person on the other line talks:

Transfer the call to your mobile phone

Press and hold Up + button for two seconds to increase microphone volume

Press and hold Down - button for two seconds to decrease microphone

If echo disappeared, transfer the call to your YD-V16 again and lower the loud speaker volume until echo is reduced/eliminated

If the echo remains, root cause of the echo might be with the network

To make a call using the voice dialing function: To enter voice dialing mode Hold the Send) button for 2 seconds

If the loudspeaker volume of the YD-V16 is too low or too high and you are

to exit and repeat the above steps for voice dialing. Note: Voice Dialing is a feature of your mobile phone. Please refer to your phone's user manual for voice command operation.

Note: If the YD-V16 failed to recognize the voice/name. Press the End \bigcirc button

· End call using the mobile handset 4. Rejecting Calls To reject a call:

To shift from YD-V16 to handset or vice versa: Press and hold the Send button for two seconds **BUTTON FUNCTIONS**

Function

7. Interchanging YD-V16 and Handset

name, the name must be stored in the phone book b) By Phone Number Phone number will be displayed if there is no record of that number in the phone book c) Withheld Number When a caller withholds his number, WITHHELD will be displayed Note: The YD-V16 do not automatically save numbers dialed directly from your mobile phone and will not be displayed. 6. Call Waiting

Note: Call Waiting is a network service, please consult your network provider for details.

Press the Send button

 and the phone will automatically switch to Line 2

To accept an incoming call during a conversation:

Press the Send button ① to switch between lines

To switch calls between the two lines:

End Call

Increase Volume

Scroll Upward

Increase Microphone Gain

 \odot

+

Button Function Operation Make / Receive call Press 1 time Voice dialing Press and hold for 2 seconds to enter voice dialing mode While conversation is ongoing, press and hold or 2 seconds 0 Conversation transfer Bluetooth® link connection Press 1 time after pairing

Press 1 time

Press 1 time

Press repeatedly until you reach desired volume leve

Press repeatedly until you reach desired volume lev

Press repeatedly until you find desired entry/menu item

Press repeatedly until you find desired entry/menu item

Press and hold for 2 seconds

To answer calls via the YD-V16: Press the Send button (1) when ring tone is heard or Answer the call via the mobile handset 3. Ending Calls To end a call: Press the End button or

Go to Menu Activated only when the line is connected CONTACT LIST ransfer phonebook contacts from mobile phone and SIM to YD-V16 via AT or OPP command CONTRAST SETTING Adjust LCD Contrast DISCONNECT BT Disconnect Bluetooth Menu QUICK DIAL With 3 memory slots for quick dialing DELETE CONTACT Delete entire phonebook conten-Press and hold for 2 seconds (Screen shows "Pair Mode") Pairing

Press 1 time

Bluetooth® Pairing Mode

Bluetooth® Disconnected

Outgoing Call

Incoming Call

AT Command Inquire

Missed Call

Bluetooth® Pairing Successful

Blinking to indicate Bluetooth® Search Mode

Operation

Press twice (screen will show "DELETE?")

LCD DISPLAY INDICATION

You may interchange the call between your handset and YD-V16 while

Reception Signal Strength Indicator (for mobile phone Call transfer to mobile during a call Voice Dialing Call Register (Outgoing Call/Incoming Call/Missed Call

AT Command Phone Book Transfer in Process

AT Command Phone Book Transfer Finished

		Scroll downward	Press repeatedly until you find desired entry/menu item		Downloading 1 OPP Phone Book Transfer in Process		
	_	Move right	Press repeatedly until you find desired entry/menu item				
		Decrease Microphone Gain	Press and hold for 2 seconds				
21							
	.ED IN	DICATION)		Do not disassemble the charger as it may expose you to cother risks. Incorrect reassembly can cause electric shock		
Г	LED Light Status		Indication		subsequently usedDo not use the charger outdoors or in damp areas		
ı	RED Light	Steady	Battery charging in progress		 Avoid charging the YD-V16 in extremely high or low temp It is recommended to charge the YD-V16 immediately whis encountered to prolong durability & standby time 		
		Blinking (every 5 seconds	Battery low; recharging is recommended	1			
Ī	BLUE Light	Blinking (every 30 second	ds) Unit is powered on				
					TROUBLE		
CARE AND MAINTENANCE Turn off the YD-V16 when not in use Attach the YD-V16 carefully and firmly to your rearview mirror (Please refer to instructions on how to attach the YD-V16 to your rearview mirror) Do not let the YD-V16 be in contact with liquid as it is not waterproof. Avoid putting it in places where there is excessive moisture and humidity. Do not expose the YD-V16 to direct sumlicht or place in areas with high temperature,				ng	If you are unable to pair your mobile phone with the YD-V16: Make sure the battery is fully charged Turn off the YD-V16 and turn it on again Turn off all other Bluetooth® devices before you start pairin Ensure your mobile handset's Bluetooth® feature is activat mobile handset user guide for specific instructions Repeat pairing procedures		

as it may result in an explosion If the YD-V16 is not in use for a prolonged period, store in a cool, dry place, free from moisture, humidity and dust Do not use abrasive cleaning solvents to clean the YD-V16 Do not expose the YD-V16 to contact with sharp objects as this will cause scratching and damage Do not stick anything inside the YD-V16 as this may damage internal components Do not attempt to disassemble the YD-V16, as it does not contain serviceable

user guide 23

Winplus Europe Tel. 44-1440-713888 Tel. 61-3-9720-4143 Winplus Australia Winplus New Zealand Tel. 62-9-5254575 Winplus Asia Tel. 852-2798-8932

HOW TO RETURN/EXCHANGE THE PRODUCT. FCC/ICC

Federal Communication Commission Interference Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

Do not disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the YD-V16 is subsequently used Do not use the charger outdoors or in damp areas Avoid charging the YD-V16 in extremely high or low temperatures It is recommended to charge the YD-V16 immediately whenever low battery power is encountered to prolong durability & standby time

TROUBLE SHOOTING

electronic devices, in between as it may cause interference transmission If all the above steps do not resolve your problem, please remove the battery for at The YD-V16 Rearview Mirror Speakerphone is compliant with and adopts the Bluetooth® Specification V1.2. However, interoperability between the device and other Bluetooth*-enabled products is not guaranteed because it depends on compatibility. For more information on the compatibility between the device and other

Turn off all other Bluetooth* devices before you start pairing Ensure your mobile handset's Bluetooth* feature is activated. Please refer to your

If the LCD display hanged or all button functions disabled: Use the RESET switch at the back of the unit 24

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with FCC RF exposure requirements, the device and the antenna for this device must be installed to ensure a minimum separation distance of 20cm or more from a person's body. Other operating configurations should be avoided. Operation is subject to the following two conditions: 1) This device may not cause interference and 2) This device must accept any interference, including interference that may cause undesired operation of the device. This device has been designed to operate with an antenna having a maximum gain of 0

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

26

Only use the manufacturer supplied charger when charging the YD-V16 Only charge the YD-V16's built-in battery in accordance with the instructions of this

Repeat pairing procedures
Ensure the YD-V16 is within a maximum of 10 meters of your mobile handset(s) or Bluetooth® enabled device and there are no obstructions, such as wall or other least 20 minutes

Bluetooth®-enabled products, please contact Customer Service.

dBi. Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.

interference by one of the following measures:

CUSTOMER SERVICE / CONTACT US For questions or issues regarding the product, please visit www.letsyada.com or contact Winplus in your area/region to speak to our customer service representative Winplus USA

Tel. 866-294-9244 Tel. 310-638-0588 You can also contact us online by visiting www.winplus.com for more information about IF YOU ARE EXPERIENCING ANY ISSUES WITH THE PRODUCT DURING OPERATION, DO NOT RETURN THE PRODUCT TO THE STORE. CONTACT WINPLUS DIRECTLY FOR INSTRUCTIONS ON