

CLARITY FIT

OPEN EAR AIR CONDUCTION

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may

Power on
press and hold the power button for 3 seconds to power on. (Blue light stays on for 1 second power on)

Power off
1: When the battery is exhausted/standby timeout/plug in the charging cable, it will automatically shut down. (Red light stays on for 1 second power off)
2: When the phone is on, press and hold the power button for 5 seconds to shut down.

Pairing mode
It will automatically enter pairing mode directly after powering on, and synchronization will automatically connect back to the last connected device.
(Red and blue light flash)

Alternately pairing
Connected Music and call / connected disconnected Manually disconnect and automatically enter pairing mode (Red and blue light flash alternately disconnected)

cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Warranty

What is covered under the 2 Year Warranty?

Monster® warrants that this product will be free from defects in workmanship and materials under normal use (Lifetime Warranty®). In a case where the product is determined to be "defective", we will repair the product free of charge. If we cannot repair the product, we will replace it for you free of charge.

How long am I covered?

You are covered for the 2 Years from Purchase

What is not covered under the Lifetime Warranty?

1. Normal wear and tear of product use.
2. Misuse, lack of care, mishandling, accidental damage, abuse or other abnormal use.
3. Use of the product other than for its intended purpose.
4. Damage caused by improper or unauthorized repair or maintenance.
5. Product that has been modified or altered.
6. Any product that is not manufactured by Monster® (including, without limitation, any non-Monster® product that is used in connection with the product).

Music

Play / Pause

Click the power button

Previous Track

Press and hold the power button for 2 seconds, then release your hand after switching

Next Track

Press and hold the volume down button for 2 seconds, then release it after switching

Volume +

Double click the power button

Volume -

Double click the volume down button

Call

Answer incoming call

click the power button

