



SMART DISPLAY

MODEL NUMBER SD2010

www.PocketRadar.com


Made in USA

Instructions:

- BASIC MENU: Hold Black Button down until desired function appears, and Release Button to execute desired function.
- ADVANCED MENU: Hold Both Buttons down until desired function appears, and Release Buttons to select desired function.
- TAP Red Button to select choice, and then TAP Black Button to lock in choice and exit.
- If Radar is not connected, *no rdr* will display.
- Battery Life (*b%t*) shows Level 1 to 4 / *U5b*
- SEE MANUAL FOR MORE DETAILS

FCC ID: WZK-PR-1003

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Power On/Off

TAP to turn on
HOLD to turn off



Mode/Recall

TAP to recall
previous 25 speeds



Ext. USB
Power In



Connect
to Radar



FCC Label and Location