AFTERGLOW®

WIRELESS **HEADSET**

TABLE OF **CONTENTS**

Headset Overview 1-2

Set Up XBox 360® 3-4

Playstation 3[®] 5-7

Wii™ 8-9

PC/Mac 10

Mobile 11

Audio Modes 12


Lighting Modes 12

Power & Charging 13

Technical Specification 13

Troubleshooting 14

HEADSET OVERVIEW:




- ON/OFF & MUTE BUTTON: Press and hold to power ON. Press and hold to power off. Once connected, button now functions as mute. Click button to mute microphone, click again to unmute.
- 2. MODE BUTTON: Click to change the audio modes. (3 modes)
- 3. RETRACTABLE NOISE-CANCELLING MICROPHONE: Extends 3.5" and adjusts with its flexible cable.
- 4. MODE INDICATION LED: Multi color LED indicator on the microphone tip tells you that you are paired, which audio mode you are in, and if you are muted.


AFTERGLOW®

WIRELESS **HEADSET**

HEADSET OVERVIEW:



- 5. VOLUME DIAL: Adjusts the master volume level.
- GAME/CHAT VOLUME BALANCE: Adjusts the balance of incoming chat and game volume levels.
- XBOX 360® TALK BACK PORT: Plug the Xbox 360 chat cable (green) and the other end of the cable into the game controller.
- 8. UNIVERSAL AUDIO LINE-IN PORT: Plug the grey color universal audio cable (gray) into this port and the other end of the cable into a sound source (e.g. iPod®, iPhone®, MP3 player) – microphone is supported.
- 9. CHARGING PORT: Plug the Play & Charge cable's mini USB connector into this port (10' black cable) and the other end into a game console or other powered USB source to charge the built-in rechargeable battery.



USB TRANSMITTER:

- 10. USB CONNECTOR: Plug into a game console or PC.
- **11. STATUS LED:** A blinking LED means headset is powered OFF. A solid light means the headset and transmitter are communicating properly.
- **12. AUDIO CABLE:** Analog audio cable; plug into the sound source (console, PC, receiver, or TV).