



Welcome to
live mobile TV.



Quick Start Guide

Battery charger with FLO TV™

for iPhone 3GS and up, iPod touch 3rd generation and up

In the box:

- Battery charger with FLO TV™
- Quick Start Guide
- Charging Guide
- Subscription Information Card
- Legal documents
- Micro USB Cable

Note: You must be within the FLO TV™ service coverage area to continue. For more information, visit flov.com/maps on your computer.

Getting Started


1. Connect to the Internet.

Make sure that your Apple device has a Wi-Fi connection to the Internet.




2. Download the App.

Search for and download the free FLO TV™ app available at the Apple App Store.



Getting Started

3. Open the FLO TV App.



Note: The app will display a message that it is connecting to the Internet.

Getting Started

4. Register your App with FLO TV.

Enter the Device ID (found on your Subscription Information card) at the prompt. When prompted, re-enter the Device ID.



Note: The app will display a confirmation message: "Registration Complete."

5. Turn on your battery charger with FLO TV™.

Slide the switch on the side of the battery charger with FLO TV™ from "Off" to "FLO TV" and wait for the FLO TV™ LED to begin **Flashing Green**. This may take up to 30 seconds.

Getting Started

6. Create a Wi-Fi connection between your Apple device and your battery charger with FLO TV™.

With the FLO TV™ service, a Wi-Fi hotspot is not necessary. Simply create a Wi-Fi connection between your Apple device and your battery charger with FLO TV™, as shown below.



In the Apple device settings, go to Wi-Fi and choose the FLO TV™ Wi-Fi link that matches your battery charger with FLO TV™.

Note: If more than one FLO TV™ Wi-Fi link appears, determine your personal FLO TV™ network by matching it to your Device ID found on the battery charger with FLO TV™ device label.

Getting Started

7. Open the App and Pair.

Open the Application and press "Pair", when prompted.




If you are in a FLO TV™ coverage area the FLO TV™ Preview Channel will appear shortly.

Note: If you don't see the FLO TV™ Preview Channel, you are not in coverage. You must be within the FLO TV™ coverage area to continue with the activation process. To check your area for FLO TV™ coverage, visit flov.com/maps.

Getting Started

8. Activate your FLO TV Service.

Go to flov.com on your computer and click on "Activate Service".




Here's the info you'll need handy:

- **Credit/Debit Card**
- **Valid Email Address**
- **Device ID & Authorization Code**


To locate the Device ID and Authorization Code, check the subscription info card that was shipped with your battery charger with FLO TV™.

If you no longer have your subscription info card, you can find your Device ID and Authorization Code in the FLO TV™ app when connected to your battery charger with FLO TV™ by navigating to: Guide > Settings > Receiver Status > Subscription Info.

Getting Started



1. Provide information as prompted.
2. Once online activation is complete, go to the FLO TV App on your Apple device and navigate to the Subscription Information screen (Guide > Settings > Receiver Status > Subscription Info) and tap the "Ready" button on the bottom of the screen.
3. Stay on the Waiting for Authorization screen and in a FLO TV coverage area until you receive a message that your subscription status has changed.



Getting Started

Note: If your battery charger with FLO TV™ is not activated within 10 minutes, try powering it off/on. If it still doesn't activate, call 877-55-FLOTV.

Note: If an error message occurs, make sure the Wi-Fi settings on your Apple device are set to your designated FLO TV™ Wi-Fi link.

Welcome to FLO TV!

From the FLO TV™ Channel Guide you can access your favorite shows.

Quick Tips

Tip: Make sure the FLO TV™ Wi-Fi link is connected each time prior to watching TV.

Tip: Use the scale icon in the upper right or double tap the screen to switch between standard mode and full screen.


Quick Tip

Change channels by swiping up or down.



Quick Tip

Explore the interface and settings to maximize your experience.



For additional help and FAQs visit flostv.com/help or call 1-877-55-FLOTV (877-553-5688)

Visit flostv.com to review the FLO TV Incorporated Customer Contact and Privacy Statement.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance to part 15 of the FCC Rules could void the user's authority to operate the equipment.

FCC Notice

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

©2010 FLO TV Incorporated, a Qualcomm company. All rights reserved. FLO and FLO TV are trademarks of Qualcomm Incorporated. All other trademarks are the property of their respective owners.

Service not available everywhere.

All programming subject to change. All sports programming subject to blackout restrictions. "Live mobile television" means the FLO TV service transmits channels in real time; no downloading, sideload or buffering.

87-K0910-1, rev B

Notes:

Device ID: _____

Authorization Code: _____

Notes: