USB Wireless Lan card user's manual WL0187/N300UA


1. Install the driver

b.


a. Insert the installation CD into your

CD-ROM driver, Double click the icon

IS AP_STA_RI2870... Setup. exe Macrovision Corp.... to start setup.




c. Choose Ralink configuration Tool and click next to go on




d. Choose optimize for wifi mode and


click next to go on




e. Choose Click Install to begin the installation and click Install to go on



f. Click Finish to end the setup



 Plug in your usb wireless LAN adapter, it will be recognized and auto installed...Just confirmed it like below:



3. Make infrastructure connection

Double click the icon in red circle

You will see:

RaUT Profile	Jaala Network	Advanced	Statisti	cs	ww	Ŵ	Ø WPS				R	R
orted by >>	O SSID	0) Channel	۵P	List >	Signal			🗆 Sh	ow dBm		
			1 /211	Bg	-	81%	-					
hidvan			11	Bg	•	81%	-					
HIDVAN_SW1			106	Bg	IJ	99%					_	
RTL8186-VPN-G	SW		11	Bg		50%	-					
zioncom	550		101	Ba		100%	-					
zioncom			101	Baf		100%	_					
zmk			106	Bq	S1.	100%	_					
Rescan	Connec	t Add to	Profile									
		t Add to						Link Oue	lity >> 1	00%		
Status	>> zioncom <-							Link Que Signal Stre				
Status Extra Info	>> zioncom <- >> Link is Up	·> 00-0E-E8-E9-B3	-84					the second se				
Status Extra Info Channel Authentication	>> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown	-> 00-0E-E8-E9-B3 TxPower:100%]	-84					Signal Stre	ngth 1 > ngth 2 >>	> 98% • 100%		
Status Extra Info Channel Authentication Encryption	>> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown >> None	-> 00-0E-E8-E9-B3 TxPower: 100%] MHz; central cha	-84					Signal Stre Signal Stre	ngth 1 > ngth 2 >>	> 98% • 100%		
Status Extra Info Channel Authentication Encryption Network Type	>> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown >> None >> Infrastruct	-> 00-0E-E8-E9-B3 TxPower: 100%] MHz; central cha ure	-84			Tr	ansmit —	Signal Stre Signal Stre Noise Stre	ngth 1 > ngth 2 >> ength >>	> 98% > 100% 26%		
Status Extra Info Channel Authentication Encryption Network Type IP Address	>> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown >> None >> Infrastruct >> 192,168.8.	-> 00-0E-E8-E9-B3 TxPower: 100%] MHz; central cha ure 13	-84			Tr	Link Spee	Signal Stre Signal Stre Noise Stre d >> 270.0 Mb	ngth 1 > ngth 2 >> ength >> ps	> 98% • 100%		
Status Extra Info Channel Authentication Encryption Network Type IP Address	<pre>>> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown >> None >> Infrastruct >> 192.168.8. >> 255.255.25</pre>	-> 00-0E-E8-E9-B3 TxPower: 100%] MHz; central cha ure 13 5.0	-84			Tr	Link Spee	Signal Stre Signal Stre Noise Stre	ngth 1 > ngth 2 >> ength >> ps	> 98% 100% 26% Max 0.000		
Status Extra Info Channel Authentication Encryption Network Type IP Address Sub Mask	 >> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown >> None >> Infrastruct >>> 192.168.8. >> 255.255.25 >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>	-> 00-0E-E8-E9-B3 TxPower: 100%] MHz; central cha ure 13 5.0	-84				Link Spee Throughpu	Signal Stre Signal Stre Noise Stre d >> 270.0 Mb	ngth 1 > ngth 2 >> ength >> ps	» 98% • 100% 26% Max		
Status Extra Info Channel Authentication Encryption Network Type IP Address Sub Mask	 >> zioncom <- >> Link is Up >> 1 <> 2412 >> Unknown >> None >> Infrastruct >>> 192.168.8. >> 255.255.25 >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>	-> 00-0E-E8-E9-B3 TxPower: 100%] MHz; central cha ure 13 5.0 1 7	-84				Link Spee Throughpu ceive	Signal Stre Signal Stre Noise Stre d >> 270.0 Mb	ngth 1 > ngth 2 >> angth >> ps ps	> 98% 100% 26% Max 0.000		

You can click the button Rescan to find which AP is in range, the will show on the window, choice one you want to connect, and click the button connect.

An infrastructure connection is accomplished. Note,please choose correct channel setting up to your law,for example,ch13 is permitted in your country,and you set your router at ch13,while you choose ch1-ch11(default setting), you will never find the AP, and you will have to choose ch1-ch13 seting in Advanced page as below.

RaUI						×
P		6	N	- Mar	A	😮 💡
Profile	Network	Advanced	Statistics	WWW	WPS	R
1			-			
Wireless mode >>	802.11 8	8/G/N mix	_	nable CCX (Cisco	Compatible eXtensions)	
			E	Turn on CCKM		
			E	Enable Radio M	easurements	
Enable TX Bu	ırst			🔲 Non-Serv	ing Channel Measurements limit 🔽	250 ms (0-2000)
Enable TCP V	Window Size					
Fast Roamin	gat -70 dBm	í				
1000 2015) 177755	- , ntication Status					
Sector Contraction of Contract	t Your Country					
11 B/G >>	0: CH1-11	-				
(1b)d //	0: CH1-11					
	1: CH1-13					
Apply	2: CH10-11 3: CH10-13					
	4: CH14					
Statu	5: CH1-14 5 > 6: CH3-9				Eink Quality>	>:100%
	o > 7: CH5-13				Signal Strength	
Channe	el >> 1 <> 2412	MHz; central char	nnel : 3		Signal Strength :	2 >> 99%
Authentication	n >> Unknown				Noise Strength	>> 26%
Encryption						
	e >> Infrastruct				Transmit	
	s >> 192.168.8.				Link Speed >> 270.0 Mbps	Max
	k >> 255.255.25				Throughput >> 1.168 Kbps	1.936
Default Gateway	y >> 192.100.0. H					Kbps
12					Receive	Max antibus dans
BW >> 40		SNR0 >			Link Speed >> 81.0 Mbps	
GI >> long	MCS >> 1	5 SNR1 >	⇒n/a		Throughput >> 25.376 Kbps	27.916
						Kbps

- 4. Some help information in Ralink Wireless utility
 - How to find out your ip address:

Profile	Network	Advanced	Statist	ics	ww	M	Ø WPS				~	
orted by >>	O SSID	0	Channel		P List :	Signal			Sł	how dBm		
			1 11	B 9	e	81%	-					
hidvan			11	Bg	•	81%	_					
HIDVAN_SW			106	Ъg	0	99%	_				_	
RTL8186-VPI			11	B g		50%	_					
zioncom			ie 1	Bg		100%	_					
zioncom			101			100%	_					
zmk			6	b g	w i	100%	-					
_												
Rescan	Connec		Profile									
Stat	us >> zioncom <-	-> 00-0E-E8-E9-B3							ality >>			
Stat Extra Ir	us >> zioncom <- ifo >> Link is Up	-> 00-0E-E8-E9-B3	-84					Link Qu Signal Stre Signal Stre				
Stat Extra Ir Chani	us >> zioncom <- ifo >> Link is Up	-> 00-0E-E8-E9-B3- TxPower:100%]	-84							>> 98% > 100%		
Stat Extra Ir Chan Authenticati	us >> zioncom <- ifo >> Link is Up nel >> 1 <> 2412	-> 00-0E-E8-E9-B3- TxPower:100%]	-84					Signal Stre Signal Stre		>> 98% > 100%		
Stat Extra Ir Chani Authenticati Encrypti Network Ty	us >> zioncom <- fo >> Link is Up hel >> 1 <> 2412 on >> Unknown on >> None pe >> Infrastruct	-> 00-0E-E8-E9-B3- TxPower: 100%) MHz; central cha	-84			Tr	ansmit —	Signal Stre Signal Stre		>> 98% > 100% > 26%		
Stat Extra Ir Chan Authenticati Encrypti Network Ty IP Addre	us >> zioncom <- fo >> Link is Up hel >> 1 <> 2412 on >> Unknown on >> None pe >> Infrastruct iss >> 192.168.8.	-> 00-0E-E8-E9-B3- TxPower: 100%) MH2; central cha :ure 13	-84			Tr	Link Spee	Signal Stre Signal Stre Noise Str d >> 270.0 Mb	ength 1 : ingth 2 > rength >: ops	>> 98% > 100%		
Stat Extra Ir Chan Authenticati Encrypti Network Ty IP Addre Sub Ma	us >> zioncom <- fo >> Link is Up hel >> 1 <> 2412 on >> Unknown on >> None pe >> Infrastruct pe >> Infrastruct ss >> 192,168.8. sk >> 255,255,25 ay >> 192,168.8.	-> 00-0E-E8-E9-B3 TxPower:100% MHz; central cha ure 13 5.0	-84			Tr	Link Spee	Signal Stre Signal Stre Noise Str	ength 1 : ingth 2 > rength >: ops	>> 98% > 100% > 26%		
Stat Extra Ir Chan Authenticati Encrypti Network Ty IP Addre Sub Ma	us >> zioncom <- fo >> Link is Up hel >> 1 <> 2412 on >> Unknown on >> None pe >> Infrastruct ss >> 192,168.8. sk >> 255,255,25	-> 00-0E-E8-E9-B3 TxPower:100% MHz; central cha ure 13 5.0	-84				Link Spee Throughpu ceive	Signal Stre Signal Stre Noise Str d >> 270.0 Mb t >> 0.000 Kb	ength 1 > rength 2 > rength >: ops ops	>> 96% > 100% > 26% Max 0.000 Kbps		
Stat Extra Ir Chan Authenticati Encrypti Network Ty IP Addre Sub Ma	us >> zioncom <- fo >> Link is Up hel >> 1 <> 2412 on >> Unknown on >> None pe >> Infrastruct pe >> Infrastruct ss >> 192,168.8. sk >> 255,255,25 ay >> 192,168.8.	-> 00-0E-E8-E9-B3 TxPower:100%] MHz; central cha ture 13 5.0 1 1 5.0 5.0 1 5.0	-84				Link Spee Throughpu ceive Link Spee	Signal Stre Signal Stre Noise Str d >> 270.0 Mb	ength 1 2 > rength 2 > ops ops ops	>> 98% > 100% > 26% Max 0.000		

5.Mske Ad-hoc mode connection

Mske an Ad-hoc SSID

Profile	Network	کی Advanced	Statistics	www.	W PS	~~
		Profile List				
					Profile Name >>	
					SSID >>	
					Network Type >>	
					Authentication >>	
					Encryption >>	
					Use 802.1x >>	
					Channel >>	
					Power Save Mode >>	
					Tx Power >>	
					RTS Threshold >>	
					Fragment Threshold >>	
	F -104	5-1			Fragment mreshold >>	
Add	Edit	Del	ete A	sctivate	Fragment mreshou >>	
	Edit			octivate	Link Quality >> 100%	
Sta		> 00-0E-E8-E9-B3		octivate		m
Sta Extra I Char	itus >> zioncom <: nfo >> Link is Up [T nnel >> 1 <> 2412	> 00-0E-E8-E9-B3 [xPower:100%]	-84	activate	Link Quality >> 100%	
Sta Extra I Char Authenticat	itus >> zioncom < nfo >> Link is Up (T inel >> 1 <> 2412 cion >> Unknown	> 00-0E-E8-E9-B3 [xPower:100%]	-84	activate	Link Quality >> 100% Signal Strength 1 >> -56 dB	m
Sta Extra I Char Authenticat Encrypt	itus >> zioncom < nfo >> Link is Up [T nnel >> 1 <> 2412 :ion >> Unknown :ion >> None	> 00-0E-E8-E9-B3 `xPower:100%] MHz; central cha	-84	activate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB	m
Sta Extra I Char Authenticat Encrypt Network T	itus >> zioncom < nfo >> Link is Up [T inel >> 1 <> 2412 :ion >> Unknown :ion >> None ype >> Infrastructu	> 00-0E-E8-E9-B3 `xPower:100%] MHz; central cha ure	-84	ictivate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB Noise Strength >> -92 dBr	m
Sta Extra I Char Authenticat Encrypt Network T IP Addr	rtus >> zioncom < nfo >> Link is Up [T nnel >> 1 <> 2412 cion >> Unknown cion >> None ype >> Infrastructu ess >> 192,168.8,1	> 00-0E-E8-E9-B3 `xPower: 100%] MHz; central cha ure 3	-84	ctivate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB Noise Strength >> -92 dBr	m
Sta Extra I Char Authenticat Encrypt Network T IP Addr Sub M	rtus >> zioncom < nfo >> Link is Up [T nnel >> 1 <> 2412 :ion >> Unknown :ion >> None ype >> Infrastructu ess >> 192,168.8,1 ask >> 255,255,255	> 00-0E-E8-E9-B3 [xPower:100%] MHz; central cha ure 3 5.0	-84	Activate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB Noise Strength >> -92 dBr Transmit Link Speed >> 270.0 Mbps Throusbout >> 0.592 Kbps	m
Sta Extra I Char Authenticat Encrypt Network T IP Addr Sub M	itus >> zioncom < nfo >> Link is Up [T nnel >> 1 <> 2412 cion >> Unknown cion >> None ype >> Infrastructu ess >> 192.168.8.1 way >> 192.168.8.1	> 00-0E-E8-E9-B3 [xPower: 100%] MHz; central cha ure 3 5.0	-84	Activate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB Noise Strength >> -92 dBn Transmit Link Speed >> 270.0 Mbps Throughput >> 0.592 Kbps 3.	in
Sta Extra I Char Authenticat Encrypt Network T IP Addr Sub M	rtus >> zioncom < nfo >> Link is Up [T nnel >> 1 <> 2412 :ion >> Unknown :ion >> None ype >> Infrastructu ess >> 192,168.8,1 ask >> 255,255,255	> 00-0E-E8-E9-B3 [xPower: 100%] MHz; central cha ure 3 5.0	-84	Activate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB Noise Strength >> -92 dBr Transmit Link Speed >> 270.0 Mbps Throughput >> 0.592 Kbps Receive	m h Nax 872 sps 11, 11,
Sta Extra I Char Authenticat Encrypt Network T IP Addr Sub M	itus >> zioncom < nfo >> Link is Up [T nnel >> 1 <> 2412 cion >> Unknown cion >> None ype >> Infrastructu ess >> 192.168.8.1 way >> 192.168.8.1	> 00-0E-E8-E9-B3 [xPower: 100%] MHz; central cha ure 3 5.0	-B4 nnel : 3	Activate	Link Quality >> 100% Signal Strength 1 >> -56 dB Signal Strength 2 >> -51 dB Noise Strength >> -92 dBr Transmit Link Speed >> 270.0 Mbps Throughput >> 0.592 Kbps Receive	iax 872

3								
Profile	LLL Network	Advanced	Statistics	www.	Ø WPS		?	R N
		Profile List						
					Profile Name >>			
					SSID >>			
					Network Type >>			
					Authentication >>			
					Encryption >>			
					Use 802.1x >>			
					Channel >>			
					Power Save Mode >>			
					Tx Power >>			
					RTS Threshold >>			
					Fragment Threshold >>			
Add	Edit	Delet	e Ac	tivate				
System (Config Autl	h.∖Encry.	8021X					_
	Profile Name >>	PROF1			Network Type >>	Adhoc 🔻	_	
	SSID >>			•	Tx Power >>	 Ad hoc 		
Pa	ower Save Mode >>	CAM Q	PS₩	_	Preamble >>	• Infrastructure		
					Channel >>	1		
	hreshold		0		2347	2347		
🗌 Fragm	nent Threshold	25	6		2346	2346		




• A

Profile Network Advanced Statistics Profile Profile VMM VPS Profile Profile VMM VPS Profile Profile	RaUI							and the second second
Profile List Profile Name >> SSID >> SSID >> Network Type >> Authentication >> Lise 802.1x >> Channel >> Channel >> Provier Save Mode >> Add Edit Delete Add Edit Delete System Config Auth. \ Encry. 8021× Profile Name >> PROF1 Network Type >> SSID >> Sinceon Tx Power >> Profile Name >> PROF1 Network Type >> SSID >> Sinceon Tx Power >> Profile Name >> PSM Channel >> Channel >> 1 2346		And a second sec	C.		Gos	0		3
Profile Name >> SSID >> Network Type >> Add Edit Delete Activate System Config Auth. \ Encry. 802:1x Profile Name >> RTS Threshold >> Profile Name >> Profile Name >> RTS Threshold => Profile Name >> Profile Name >> <t< td=""><td>Prome</td><td>Network</td><td></td><td>statistics</td><td>VV/VV/</td><td>WVP5</td><td></td><td>1</td></t<>	Prome	Network		statistics	VV/VV/	WVP5		1
SID >> SID >> Network Type >> Authentication >> Encryption >> Use 802.1x >> Channel >> Power Save Mode >> Tx Power >> RTS Threshold >> System Config Auth. \ Encry. 8021x Profile Name >> PROF1 SID >> foncor Power Save Mode >> Quity Power S			Profile List			Drofile Name as		
Network Type >> Authentication >> Encryption >> Use 802.1x >> Channel >> Power Save Mode >> System Config Auth. Encry. 802.1x Profile Name >> PROF1 Silb >> Encryption Power Save Mode >> Power Save Mode >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Profile Name >> Power Save Mode >> Channel >> Profile Name >> Profile Name >> Profile Name >> Power Save Mode >> Channel >> Profile Name >>								
Authentication >> Encryption >> Use 802, 1x >> Channel >> Power Save Mode >> System Config Auth. \ Encry. 8021X Profile Name >> Power Save Mode >> Channel >> Tx Power >> Add Edit Delete Add Edit Delete Activate System Config Auth. \ Encry. 8021X Profile Name >> Profile Name >> PROF1 SID >> Tomeon Power Save Mode >> PSM Power Save Mode >> Channel >> Tx Power >> Auto Power Save Mode >> PSM Preamble >> Auto Channel >> 1 Pragment Threshold 2347 2346 2346								
Encryption >> Use 802.1x >> Channel >> Power Save Mode >> Add Edit Delete Add System Config Auth. Encry. 8021X: Profile Name >> PROF1 SID >> SiD >> Channel >> Power Save Mode >> Channel >> Power Save Mode >> Channel >> Preamble >> Auto Preamble >> Auto Channel >> Image: Profile Network Type >> Auto Preamble >> Auto Preamble >> Auto Preamble >> Image: Profile Network Type >> Auto Preamble >> Image: Profile Network Type >> Auto Preamble >> Image: Profile Network Type >> Auto Image: Profile Network Type >> Auto </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
Use 802.1x >> Channel >> Power Save Mode >> Add Edit Delete Activate System Config Auth. \ Encry. 8021X Profile Name >> Profile Name >> PROF1 SID >> Element Power Save Mode >> @ Power Save Mode >> @ Power Save Mode >> @ Pagment Threshold 2347 2346 2346								
Channel >> Power Save Mode >> Tx Power Save Mode >> Tx Power Save Mode >> Tx Power Save Mode >> Add Edit Delete System Config Auth. \ Encry. 8021x Profile Name >> PBoPE1 Tx Power >> SID >> Eloncon Tx Power >> Power Save Mode >> Channel > T Power Save Mode >> Channel > T Progenent Threshold 256 2347 2346 2340 2346 2346 2346								
Add Edit Delete Activate Add Edit Delete Activate System Config Auth. \ Encry. 8021x Profile Name >> PROF1 Network Type >> Adhoc SID >> Image: Conconsistion of the state of the s								
Add Edit Delete Activate System Config Auth. \ Encry. 8021X Profile Name >> PROF1 SSID >> Sioncom Power Save Mode >> CAM Power Save Mode >> Power Save Mode >> Power Save						Power Save Mode >>		
Add Edit Delete Activate System Config Auth. \ Encry. 8021x Profile Name >> PROF1 Network Type >> Adhoc SID >> Ionroom I Xato I Power Save Mode >> CAM PSM Preamble >> Auto I In RTS Threshold 0 2347 2347 2346 In RTS Threshold 256 2346 2346 2346						T× Power >>		
Add Edit Delete Activate System Config Auth. \ Encry. 3021X Profile Name >> PROF1 Network Type >> Adhoc SSID >> ioncon I Power Save Mode >> CAM PSM Image: RTS Threshold 0 2347 Image: Fragment Threshold 256 2346						RTS Threshold >>		
System Config Auth. \ Encry. 8021X Profile Name >> PROF1 Network Type >> Adhoc SID >> icincom Image: Control icincom Image: Co						Fragment Threshold >>		
SSID >> ioncom Tx Power >> Auto Power Save Mode >> CAM PSM Image: Channel and the state of the state					tivate			
Power Save Mode >> CAM PSM Power Save Mode >> CAM PSM Preamble >> Auto Channel >> 1 Channel >> 1 Fragment Threshold 256 2346 2346		Profile Name >>	PROF1			Network Type >>	Adhoc	-
Power Save Mode >> CAM PSM RTS Threshold 0 2347 Fragment Threshold 256 2346		SSID >>	zioncom		-	T× Power >>	Auto	-
RTS Threshold 0 2347 2347 Fragment Threshold 256 2346 2346	Desi			ocu		Preamble >>	Auto	-
Fragment Threshold 256 2346 2346	P00	ner save woue >>		r-Sivi		Channel >>	1	-
	🔲 RTS Thr	reshold		o		2347	2347	
OK Cancel	Fragme	ent Threshold	2!	i6		2346	2346	
OK Cancel								
OK Cancel						12		
				OK	Ca	ncei		

OK Cancel





5.2 Setup static IP address for the AD-Hoc link

•A At its property page,double click item Internet Protocol(TCP/IP)

Heads - Hor E Q Search ddress P Network and Dial-up Co	h ChiFolders (3)History Chi Pit X 20 [[]+	→ ∂G0
		- @Go
Network and Dial- up Connections	Make New Local Area Local Area Local Area Connection Connection 3 Connection 5	
ocal Area Connection 3	al Area Connection 3 Properties	
	eneral Sharing Connect using:	
Ralink Wireless LAN Card V2 #1	B Ralink Wireless LAN Card V2 #10	
	Configure Components checked are used by this connection:	
	Install Uninstall Properties	
	Allows your computer to access resources on a Microsoft network.	
ink Wireless LAN Card V2 #10	Show icon in taskbar when connected	_

• B You will get

supports strator for
vanced
Cancel

ullet C Fill the IP address blank, example as

below:

rnet Protocol (TCP/IP) Pro	perties	1
eneral		
	d automatically if your network support ed to ask your network administrator f	
C Dbtain an IP address autor	natically	
Use the following IP address	ss:	
IP address:	192.168.1.1	3.
Subnet mask:	255 . 255 . 255 . 0)
Default gateway:		
C Obtain DNS server address	s automatically	
Use the following DNS service		
Preferred DNS server:		
Alternate DNS server:	· · · ·	
	Advanced	ł
	OK) Co	ncel

D Click ok to finish the setup

Ralink Wireless LAN Card V2 #10 Confi ponents checked are used by this connection: Configuration:	gure
ponents checked are used by this connection:	gure
	Contract of the Parameter
Client for Microsoft Networks	
📇 File and Printer Sharing for Microsoft Networks	
Call Contract (IEEE 802.1x) v3.4.3.0	
Internet Protocol (TCP/IP)	
Install Uninstall Properti	e 2
	100000
escription	
ransmission Control Protocol/Internet Protocol. The defa	ult
vide area network protocol that provides communication cross diverse interconnected networks	
Show icon in taskbar when connected	

5.3 Ad-Hoc setup for one point accomplished 5.4 Setup another Ad-hoc point as step $A \ B \ C \ D$.

5.5 Ad-hoc mode link accomplished.And you can visit each other.

Note:To make an Ad-Hoc mode link.Do remember to choice the same channel.Its static IP address should be in the same netsub,and the SSID should be the same too.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure

Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

This equipment complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:

(1) This device may not cause harmful

interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.