

Remote user manual

Insert input plug TS-C7 into 120V60Hz power socket, Connect output socket TS25 with the electrical appliances Away from the host within 15M
By using the remote control buttons to achieve different output modes:By
pressing key A of the remote control to achieve the first output mode;By
pressing key B of the remote control to achieve the second output mode;
By pressing key A + B of the remote control to achieve the third output
mode;By pressing the OFF button of the remote control to stop any
output .

FCC ID: XA8YKQ5A2R

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received,
including interference that may cause undesired operation.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Contact Tel : (86)0712-4488360

Contact Fax : (86)0712-4488366

dawei_20040315@163.com