



PHOTOGRAPHS OF THE TEST CONFIGURATION

Set UUT as Master mode (Radar injected into Master)



Reference No.: BEMV-WTW-P20070441-1 Page No. 1 / 2





Reference No.: BEMV-WTW-P20070441-1 Page No. 2 / 2