






1-N77-3700-3980-PC2-30-60-H-8-CP-64QAM-Outer_Full-162@0-Ant3-57.987-60.99-<60-PASS



1-N77-3700-3980-PC2-30-60-H-9-CP-256QAM-Outer_Full-162@0-Ant3-57.995-61.01-<60-PASS



1-N77-3700-3980-PC2-30-70-L-1-DFT-QPSK-Outer_Full-180@0-Ant3-64.415-68.07-<70-PASS



1-N77-3700-3980-PC2-30-70-L-2-DFT-PI2BPSK-Outer_Full-180@0-Ant3-64.653-68.16-≤70-PASS




1-N77-3700-3980-PC2-30-70-L-3-DFT-16QAM-Outer_Full-180@0-Ant3-64.370-68.08-≤70-PASS



1-N77-3700-3980-PC2-30-70-L-4-DFT-64QAM-Outer_Full-180@0-Ant3-64.564-68.07-≤70-PASS




1-N77-3700-3980-PC2-30-70-L-5-DFT-256QAM-Outer_Full-180@0-Ant3-64.486-68.14-<=70-PASS



1-N77-3700-3980-PC2-30-70-L-6-CP-QPSK-Outer_Full-189@0-Ant3-67.798-71.38-<=70-PASS



1-N77-3700-3980-PC2-30-70-L-7-CP-16QAM-Outer_Full-189@0-Ant3-67.726-71.33-<=70-PASS




1-N77-3700-3980-PC2-30-70-L-8-CP-64QAM-Outer_Full-189@0-Ant3-67.871-71.50-≤70-PASS




1-N77-3700-3980-PC2-30-70-L-9-CP-256QAM-Outer_Full-189@0-Ant3-67.783-71.36-≤70-PASS



1-N77-3700-3980-PC2-30-70-M-1-DFT-QPSK-Outer_Full-180@0-Ant3-64.498-68.07-≤70-PASS




1-N77-3700-3980-PC2-30-70-M-2-DFT-PI2BPSK-Outer_Full-180@0-Ant3-64.684-68.21-<70-PASS




1-N77-3700-3980-PC2-30-70-M-3-DFT-16QAM-Outer_Full-180@0-Ant3-64.475-68.21-<70-PASS



1-N77-3700-3980-PC2-30-70-M-4-DFT-64QAM-Outer_Full-180@0-Ant3-64.641-68.05-<70-PASS



1-N77-3700-3980-PC2-30-70-M-5-DFT-256QAM-Outer_Full-180@0-Ant3-64.576-68.02-<=70-PASS




1-N77-3700-3980-PC2-30-70-M-6-CP-QPSK-Outer_Full-189@0-Ant3-67.891-71.40-<=70-PASS



1-N77-3700-3980-PC2-30-70-M-7-CP-16QAM-Outer_Full-189@0-Ant3-67.826-71.33-<=70-PASS




1-N77-3700-3980-PC2-30-70-M-8-CP-64QAM-Outer_Full-189@0-Ant3-67.938-71.55-≤70-PASS




1-N77-3700-3980-PC2-30-70-M-9-CP-256QAM-Outer_Full-189@0-Ant3-67.868-71.46-≤70-PASS



1-N77-3700-3980-PC2-30-70-H-1-DFT-QPSK-Outer_Full-180@0-Ant3-64.378-68.04-≤70-PASS




1-N77-3700-3980-PC2-30-70-H-2-DFT-PI2BPSK-Outer_Full-180@0-Ant3-64.624-68.17-<70-PASS



1-N77-3700-3980-PC2-30-70-H-3-DFT-16QAM-Outer_Full-180@0-Ant3-64.378-68.12-<70-PASS



1-N77-3700-3980-PC2-30-70-H-4-DFT-64QAM-Outer_Full-180@0-Ant3-64.555-68.07-<70-PASS



1-N77-3700-3980-PC2-30-70-H-5-DFT-256QAM-Outer_Full-180@0-Ant3-64.465-68.09-<70-PASS



1-N77-3700-3980-PC2-30-70-H-6-CP-QPSK-Outer_Full-189@0-Ant3-67.850-71.39-<70-PASS



1-N77-3700-3980-PC2-30-70-H-7-CP-16QAM-Outer_Full-189@0-Ant3-67.736-71.31-<70-PASS




1-N77-3700-3980-PC2-30-70-H-8-CP-64QAM-Outer_Full-189@0-Ant3-67.864-71.48-<70-PASS




1-N77-3700-3980-PC2-30-70-H-9-CP-256QAM-Outer_Full-189@0-Ant3-67.807-71.38-<70-PASS



1-N77-3700-3980-PC2-30-80-L-1-DFT-QPSK-Outer_Full-216@0-Ant3-77.208-81.25-<80-PASS



1-N77-3700-3980-PC2-30-80-L-2-DFT-PI2BPSK-Outer_Full-216@0-Ant3-77.339-81.25-≤80-PASS




1-N77-3700-3980-PC2-30-80-L-3-DFT-16QAM-Outer_Full-216@0-Ant3-77.200-81.17-≤80-PASS



1-N77-3700-3980-PC2-30-80-L-4-DFT-64QAM-Outer_Full-216@0-Ant3-77.340-81.25-≤80-PASS



1-N77-3700-3980-PC2-30-80-L-5-DFT-256QAM-Outer_Full-216@0-Ant3-77.304-81.23-<80-PASS



1-N77-3700-3980-PC2-30-80-L-6-CP-QPSK-Outer_Full-217@0-Ant3-77.774-81.60-<80-PASS



1-N77-3700-3980-PC2-30-80-L-7-CP-16QAM-Outer_Full-217@0-Ant3-77.729-81.57-<80-PASS




1-N77-3700-3980-PC2-30-80-L-8-CP-64QAM-Outer_Full-217@0-Ant3-77.725-81.58-<80-PASS



1-N77-3700-3980-PC2-30-80-L-9-CP-256QAM-Outer_Full-217@0-Ant3-77.722-81.61-<80-PASS



1-N77-3700-3980-PC2-30-80-M-1-DFT-QPSK-Outer_Full-216@0-Ant3-77.293-81.29-<80-PASS



1-N77-3700-3980-PC2-30-80-M-2-DFT-PI2BPSK-Outer_Full-216@0-Ant3-77.437-81.29-<80-PASS



1-N77-3700-3980-PC2-30-80-M-3-DFT-16QAM-Outer_Full-216@0-Ant3-77.342-81.29-<80-PASS



1-N77-3700-3980-PC2-30-80-M-4-DFT-64QAM-Outer_Full-216@0-Ant3-77.430-81.17-<80-PASS




1-N77-3700-3980-PC2-30-80-M-5-DFT-256QAM-Outer_Full-216@0-Ant3-77.407-81.20-≤80-PASS



1-N77-3700-3980-PC2-30-80-M-6-CP-QPSK-Outer_Full-217@0-Ant3-77.942-81.72-≤80-PASS



1-N77-3700-3980-PC2-30-80-M-7-CP-16QAM-Outer_Full-217@0-Ant3-77.933-81.57-≤80-PASS




1-N77-3700-3980-PC2-30-80-M-8-CP-64QAM-Outer_Full-217@0-Ant3-77.829-81.66-≤80-PASS




1-N77-3700-3980-PC2-30-80-M-9-CP-256QAM-Outer_Full-217@0-Ant3-77.794-81.64-≤80-PASS




1-N77-3700-3980-PC2-30-80-H-1-DFT-QPSK-Outer_Full-216@0-Ant3-77.299-81.32-≤80-PASS



1-N77-3700-3980-PC2-30-80-H-2-DFT-PI2BPSK-Outer_Full-216@0-Ant3-77.368-81.29-≤80-PASS




1-N77-3700-3980-PC2-30-80-H-3-DFT-16QAM-Outer_Full-216@0-Ant3-77.243-81.24-≤80-PASS



1-N77-3700-3980-PC2-30-80-H-4-DFT-64QAM-Outer_Full-216@0-Ant3-77.373-81.24-≤80-PASS



1-N77-3700-3980-PC2-30-80-H-5-DFT-256QAM-Outer_Full-216@0-Ant3-77.357-81.19-≤80-PASS



1-N77-3700-3980-PC2-30-80-H-6-CP-QPSK-Outer_Full-217@0-Ant3-77.906-81.64-≤80-PASS



1-N77-3700-3980-PC2-30-80-H-7-CP-16QAM-Outer_Full-217@0-Ant3-77.867-81.68-≤80-PASS



1-N77-3700-3980-PC2-30-80-H-8-CP-64QAM-Outer_Full-217@0-Ant3-77.763-81.64-≤80-PASS




1-N77-3700-3980-PC2-30-80-H-9-CP-256QAM-Outer_Full-217@0-Ant3-77.767-81.65-≤80-PASS




1-N77-3700-3980-PC2-30-90-L-1-DFT-QPSK-Outer_Full-240@0-Ant3-85.837-90.33-≤90-PASS



1-N77-3700-3980-PC2-30-90-L-2-DFT-PI2BPSK-Outer_Full-240@0-Ant3-85.891-90.40-<=90-PASS



1-N77-3700-3980-PC2-30-90-L-3-DFT-16QAM-Outer_Full-240@0-Ant3-85.832-90.35-<=90-PASS



1-N77-3700-3980-PC2-30-90-L-4-DFT-64QAM-Outer_Full-240@0-Ant3-85.727-90.38-<=90-PASS



1-N77-3700-3980-PC2-30-90-L-5-DFT-256QAM-Outer_Full-240@0-Ant3-85.733-90.41-<90-PASS



1-N77-3700-3980-PC2-30-90-L-6-CP-QPSK-Outer_Full-245@0-Ant3-87.820-92.19-<90-PASS



1-N77-3700-3980-PC2-30-90-L-7-CP-16QAM-Outer_Full-245@0-Ant3-87.985-92.25-<90-PASS



1-N77-3700-3980-PC2-30-90-L-8-CP-64QAM-Outer_Full-245@0-Ant3-87.626-92.28-<90-PASS




1-N77-3700-3980-PC2-30-90-L-9-CP-256QAM-Outer_Full-245@0-Ant3-87.588-92.32-<90-PASS



1-N77-3700-3980-PC2-30-90-M-1-DFT-QPSK-Outer_Full-240@0-Ant3-85.969-90.47-<90-PASS



1-N77-3700-3980-PC2-30-90-M-2-DFT-PI2BPSK-Outer_Full-240@0-Ant3-85.998-90.45-<90-PASS



1-N77-3700-3980-PC2-30-90-M-3-DFT-16QAM-Outer_Full-240@0-Ant3-85.975-90.51-<90-PASS



1-N77-3700-3980-PC2-30-90-M-4-DFT-64QAM-Outer_Full-240@0-Ant3-85.864-90.36-<90-PASS



1-N77-3700-3980-PC2-30-90-M-5-DFT-256QAM-Outer_Full-240@0-Ant3-85.905-90.31-<90-PASS




1-N77-3700-3980-PC2-30-90-M-6-CP-QPSK-Outer_Full-245@0-Ant3-87.991-92.25-<90-PASS



1-N77-3700-3980-PC2-30-90-M-7-CP-16QAM-Outer_Full-245@0-Ant3-88.151-92.27-<90-PASS



1-N77-3700-3980-PC2-30-90-M-8-CP-64QAM-Outer_Full-245@0-Ant3-87.811-92.43-<90-PASS



1-N77-3700-3980-PC2-30-90-M-9-CP-256QAM-Outer_Full-245@0-Ant3-87.783-92.37-<90-PASS



1-N77-3700-3980-PC2-30-90-H-1-DFT-QPSK-Outer_Full-240@0-Ant3-85.913-90.40-<90-PASS




1-N77-3700-3980-PC2-30-90-H-2-DFT-PI2BPSK-Outer_Full-240@0-Ant3-85.968-90.46-≤90-PASS




1-N77-3700-3980-PC2-30-90-H-3-DFT-16QAM-Outer_Full-240@0-Ant3-85.858-90.48-≤90-PASS



1-N77-3700-3980-PC2-30-90-H-4-DFT-64QAM-Outer_Full-240@0-Ant3-85.804-90.38-≤90-PASS



1-N77-3700-3980-PC2-30-90-H-5-DFT-256QAM-Outer_Full-240@0-Ant3-85.797-90.41-≤90-PASS



1-N77-3700-3980-PC2-30-90-H-6-CP-QPSK-Outer_Full-245@0-Ant3-87.935-92.21-≤90-PASS



1-N77-3700-3980-PC2-30-90-H-7-CP-16QAM-Outer_Full-245@0-Ant3-88.060-92.32-≤90-PASS



1-N77-3700-3980-PC2-30-90-H-8-CP-64QAM-Outer_Full-245@0-Ant3-87.730-92.36-<90-PASS



1-N77-3700-3980-PC2-30-90-H-9-CP-256QAM-Outer_Full-245@0-Ant3-87.734-92.37-<90-PASS



1-N77-3700-3980-PC2-30-100-L-1-DFT-QPSK-Outer_Full-270@0-Ant3-96.879-101.7-<100-PASS



1-N77-3700-3980-PC2-30-100-L-2-DFT-PI2BPSK-Outer_Full-270@0-Ant3-96.874-101.7-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-3-DFT-16QAM-Outer_Full-270@0-Ant3-96.556-101.6-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-4-DFT-64QAM-Outer_Full-270@0-Ant3-96.911-101.8-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-5-DFT-256QAM-Outer_Full-270@0-Ant3-96.944-101.8-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-6-CP-QPSK-Outer_Full-273@0-Ant3-97.824-102.7-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-7-CP-16QAM-Outer_Full-273@0-Ant3-97.873-102.8-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-8-CP-64QAM-Outer_Full-273@0-Ant3-98.166-102.8-≤100-PASS



1-N77-3700-3980-PC2-30-100-L-9-CP-256QAM-Outer_Full-273@0-Ant3-98.167-102.8-≤100-PASS



1-N77-3700-3980-PC2-30-100-M-1-DFT-QPSK-Outer_Full-270@0-Ant3-96.922-101.7-≤100-PASS




1-N77-3700-3980-PC2-30-100-M-2-DFT-PI2BPSK-Outer_Full-270@0-Ant3-96.956-101.7-≤100-PASS



1-N77-3700-3980-PC2-30-100-M-3-DFT-16QAM-Outer_Full-270@0-Ant3-96.662-101.7-≤100-PASS



1-N77-3700-3980-PC2-30-100-M-4-DFT-64QAM-Outer_Full-270@0-Ant3-97.005-101.8-≤100-PASS



1-N77-3700-3980-PC2-30-100-M-5-DFT-256QAM-Outer_Full-270@0-Ant3-97.063-101.7-≤100-PASS




1-N77-3700-3980-PC2-30-100-M-6-CP-QPSK-Outer_Full-273@0-Ant3-97.975-102.9-≤100-PASS



1-N77-3700-3980-PC2-30-100-M-7-CP-16QAM-Outer_Full-273@0-Ant3-98.018-104.9-≤100-PASS



1-N77-3700-3980-PC2-30-100-M-8-CP-64QAM-Outer_Full-273@0-Ant3-98.301-103.0-≤100-PASS




1-N77-3700-3980-PC2-30-100-M-9-CP-256QAM-Outer_Full-273@0-Ant3-98.289-102.9-≤100-PASS



1-N77-3700-3980-PC2-30-100-H-1-DFT-QPSK-Outer_Full-270@0-Ant3-96.869-101.6-≤100-PASS



1-N77-3700-3980-PC2-30-100-H-2-DFT-PI2BPSK-Outer_Full-270@0-Ant3-96.886-101.7-≤100-PASS




1-N77-3700-3980-PC2-30-100-H-3-DFT-16QAM-Outer_Full-270@0-Ant3-96.632-101.6-≤100-PASS



1-N77-3700-3980-PC2-30-100-H-4-DFT-64QAM-Outer_Full-270@0-Ant3-96.961-101.7-≤100-PASS



1-N77-3700-3980-PC2-30-100-H-5-DFT-256QAM-Outer_Full-270@0-Ant3-96.974-105.4-≤100-PASS




1-N77-3700-3980-PC2-30-100-H-6-CP-QPSK-Outer_Full-273@0-Ant3-97.919-103.0-≤100-PASS



1-N77-3700-3980-PC2-30-100-H-7-CP-16QAM-Outer_Full-273@0-Ant3-97.960-106.6-≤100-PASS




1-N77-3700-3980-PC2-30-100-H-8-CP-64QAM-Outer_Full-273@0-Ant3-98.229-117.9-≤100-PASS




1-N77-3700-3980-PC2-30-100-H-9-CP-256QAM-Outer_Full-273@0-Ant3-98.261-113.1-≤100-PASS

Band Edge for SA


Test Graphs



1-N77-3700-3980-PC2-30-10-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3700.00-27.91--40.91-PASS




1-N77-3700-3980-PC2-30-10-L-3-DFT-PI2BPSK-Outer_Full-24@0-Ant3-3694.97-23.93--36.93-PASS



1-N77-3700-3980-PC2-30-10-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3700.00-27.83--40.83-PASS




1-N77-3700-3980-PC2-30-10-L-6-CP-QPSK-Outer_Full-24@0-Ant3-3698.78-21.76--34.76-PASS



1-N77-3700-3980-PC2-30-10-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@23-Ant3-3980.00-26.84--39.84-PASS




1-N77-3700-3980-PC2-30-10-H-3-DFT-PI2BPSK-Outer_Full-24@0-Ant3-3985.01-23.38--36.38-PASS




1-N77-3700-3980-PC2-30-10-H-5-CP-QPSK-Edge_1RB_Right-1@23-Ant3-3980.01-27.65--40.65-PASS




1-N77-3700-3980-PC2-30-10-H-6-CP-QPSK-Outer_Full-24@0-Ant3-3981.45-20.99--33.99-PASS



1-N77-3700-3980-PC2-30-15-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3699.99-26.72--39.72-PASS




1-N77-3700-3980-PC2-30-15-L-3-DFT-PI2BPSK-Outer_Full-36@0-Ant3-3694.88-22.65--35.65-PASS



1-N77-3700-3980-PC2-30-15-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3699.99-27.87--40.87-PASS




1-N77-3700-3980-PC2-30-15-L-6-CP-QPSK-Outer_Full-38@0-Ant3-3698.82-22.68--35.68-PASS



1-N77-3700-3980-PC2-30-15-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@37-Ant3-3980.01-25.26--38.26-PASS




1-N77-3700-3980-PC2-30-15-H-3-DFT-PI2BPSK-Outer_Full-36@0-Ant3-3985.02-22.57--35.57-PASS




1-N77-3700-3980-PC2-30-15-H-5-CP-QPSK-Edge_1RB_Right-1@37-Ant3-3980.02-25.98--38.98-PASS




1-N77-3700-3980-PC2-30-15-H-6-CP-QPSK-Outer_Full-38@0-Ant3-3985.12-21.65--34.65-PASS



1-N77-3700-3980-PC2-30-20-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3692.07-28.14--41.14-PASS




1-N77-3700-3980-PC2-30-20-L-3-DFT-PI2BPSK-Outer_Full-50@0-Ant3-3692.28-21.43--34.43-PASS




1-N77-3700-3980-PC2-30-20-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3693.28-28.60--41.60-PASS




1-N77-3700-3980-PC2-30-20-L-6-CP-QPSK-Outer_Full-51@0-Ant3-3693.66-22.96--35.96-PASS




1-N77-3700-3980-PC2-30-20-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@50-Ant3-3988.01-26.47--39.47-PASS




1-N77-3700-3980-PC2-30-20-H-3-DFT-PI2BPSK-Outer_Full-50@0-Ant3-3987.16-22.46--35.46-PASS




1-N77-3700-3980-PC2-30-20-H-5-CP-QPSK-Edge_1RB_Right-1@50-Ant3-3985.13-27.78--40.78-PASS




1-N77-3700-3980-PC2-30-20-H-6-CP-QPSK-Outer_Full-51@0-Ant3-3985.91-21.89--34.89-PASS




1-N77-3700-3980-PC2-30-25-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3699.97-28.59--41.79-PASS




1-N77-3700-3980-PC2-30-25-L-3-DFT-PI2BPSK-Outer_Full-64@0-Ant3-3690.10-22.55--35.55-PASS




1-N77-3700-3980-PC2-30-25-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3700.00-27.88--41.08-PASS




1-N77-3700-3980-PC2-30-25-L-6-CP-QPSK-Outer_Full-65@0-Ant3-3694.84-22.04--35.04-PASS




1-N77-3700-3980-PC2-30-25-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@64-Ant3-3980.02-26.66--39.86-PASS




1-N77-3700-3980-PC2-30-25-H-3-DFT-PI2BPSK-Out_ Full-64@0-Ant3-3989.91-24.30--37.30-PASS




1-N77-3700-3980-PC2-30-25-H-5-CP-QPSK-Edge_ 1RB_Right-1@64-Ant3-3980.00-27.97--41.17-PASS




1-N77-3700-3980-PC2-30-25-H-6-CP-QPSK-Out_ Full-65@0-Ant3-3987.97-21.90--34.90-PASS




1-N77-3700-3980-PC2-30-30-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3699.99-25.50--38.50-PASS




1-N77-3700-3980-PC2-30-30-L-3-DFT-PI2BPSK-Outer_Full-75@0-Ant3-3690.28-24.72--37.72-PASS




1-N77-3700-3980-PC2-30-30-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3699.97-25.91--38.91-PASS




1-N77-3700-3980-PC2-30-30-L-6-CP-QPSK-Outer_Full-78@0-Ant3-3694.55-22.29--35.29-PASS



1-N77-3700-3980-PC2-30-30-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@77-Ant3-3980.00-25.47--38.47-PASS




1-N77-3700-3980-PC2-30-30-H-3-DFT-PI2BPSK-Outer_Full-75@0-Ant3-3989.90-24.57--37.57-PASS



1-N77-3700-3980-PC2-30-30-H-5-CP-QPSK-Edge_1RB_Right-1@77-Ant3-3980.02-25.95--38.95-PASS




1-N77-3700-3980-PC2-30-30-H-6-CP-QPSK-Outer_Full-78@0-Ant3-3985.12-22.14--35.14-PASS




1-N77-3700-3980-PC2-30-40-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3700.00-15.39--28.39-PASS




1-N77-3700-3980-PC2-30-40-L-3-DFT-PI2BPSK-Outter_Full-100@0-Ant3-3700.00-19.47--32.47-PASS




1-N77-3700-3980-PC2-30-40-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3700.00-13.20--26.20-PASS




1-N77-3700-3980-PC2-30-40-L-6-CP-QPSK-Outter_Full-106@0-Ant3-3699.97-21.27--34.27-PASS




1-N77-3700-3980-PC2-30-40-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@105-Ant3-3980.00-16.00--29.00-PASS




1-N77-3700-3980-PC2-30-40-H-3-DFT-PI2BPSK-Outer_Full-100@0-Ant3-3980.15-25.17--38.17-PASS




1-N77-3700-3980-PC2-30-40-H-5-CP-QPSK-Edge_1RB_Right-1@105-Ant3-3980.00-15.86--28.86-PASS




1-N77-3700-3980-PC2-30-40-H-6-CP-QPSK-Outer_Full-106@0-Ant3-3980.78-21.10--34.10-PASS




1-N77-3700-3980-PC2-30-50-L-1-DFT-PI2BPSK-Edge_1RB_Left-1@0-Ant3-3699.99-23.34--36.34-PASS




1-N77-3700-3980-PC2-30-50-L-3-DFT-PI2BPSK-Outer_Full-128@0-Ant3-3699.96-21.53--34.53-PASS




1-N77-3700-3980-PC2-30-50-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant3-3699.95-23.82--36.82-PASS




1-N77-3700-3980-PC2-30-50-L-6-CP-QPSK-Outer_Full-133@0-Ant3-3699.92-22.37--35.37-PASS




1-N77-3700-3980-PC2-30-50-H-2-DFT-PI2BPSK-Edge_1RB_Right-1@132-Ant3-3980.02-21.94--34.94-PAS



1-N77-3700-3980-PC2-30-50-H-3-DFT-PI2BPSK-Outet_Full-128@0-Ant3-3980.65-23.88--36.88-PASS



1-N77-3700-3980-PC2-30-50-H-5-CP-QPSK-Edge_1RB_Right-1@132-Ant3-3980.01-22.31--35.31-PASS



1-N77-3700-3980-PC2-30-50-H-6-CP-QPSK-Outet_Full-133@0-Ant3-3980.93-21.69--34.69-PASS