
User Manual

Model:WSRE202 Brand:WISTAR

1.Product Appearance



RE 202


2. Technique Data

- Power: 3V Model: CR2032
- Working Temperature: -10 ℃ to +60 ℃ (LCD)
- Working Temperature: -20 ℃ to +60 ℃ (Non- LCD) • Working Currency: ≤12mA
- Code: Rolling Code
- Frequency: 433.92MHz

5 ... 5 . 11/1

Battery:Rated Voltage: 3V Capacity: 210mAh

3. LCD Multi-Channel (take 8-channel emitter as an example)



Channel A&channel B control two receive respectively without interference



Press UP and DOWN buttons of A channel simultaneously Then short press the STOP button of A channel, now



Then short press the STOP button of A channel, no the code learning of current channel is successful. Choose B channel to learn code in the same way.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.