

QUICK START GUIDE
GUIDE DE DÉMARRAGE RAPIDE



IMPORTANT READ BEFORE USING
IMPORTANT LIRE AVANT UTILISATION
Any questions? Des questions?
turtlebeach.com/support

IMPORTANT PLEASE MAKE SURE YOUR HEADSET IS UPDATED WITH THE LATEST FIRMWARE.

IMPORTANT VEUILLEZ VOUS ASSURER QUE VOTRE CASQUE DISPOSE DE LA DERNIÈRE VERSION DU MICROLOGICIEL.

Connect to the Turtle Beach Audio Hub for Windows or Mac® to update firmware.
Connectez-vous au Turtle Beach Audio Hub pour Windows ou Mac® afin de mettre à jour le micrologiciel.


turtlebeach.com/audihub

CONTENTS CONTENU DE LA BOÎTE



- A Stealth™ 600 Gen 2 MAX Headset
B USB-A Transmitter
C USB-C Charging Cable

HEADSET CONTROLS COMMANDES SUR CASQUE



SUPERHUMAN HEARING™

Use Superhuman Hearing™ Mode to pinpoint quiet audio cues like enemy footsteps and weapon reloads.
Microphone Mute
PRESETS | PRÉSETS D'ÉQUALISATION
Signature Sound | Son emblématique
Bass Boost | Amplification des basses
Bass + Treble Boost | Amplification des basses et des aigus
Vocal Boost | Amplification vocal

SETUP FOR XBOX CONFIGURATION POUR XBOX

1. Put the transmitter into "XBOX" mode.
2. Connect transmitter to USB port.
3. Power on headset.
4. Wait for headset & transmitter to pair.

ES 1. Pon el transmisor en modo XBOX.
IT 1. Metti il trasmettitore in modalità "XBOX".
PT 1. Coloque o transmissor em modo "XBOX".
SE 1. Ställ in sändaren på "Xbox"-läget.
NL 1. Zet de zender in de Xbox-modus.

SURROUND SOUND FOR XBOX (ONLY AVAILABLE ON XBOX) SON SURROUND POUR XBOX (DISPONIBLE UNIQUEMENT SUR XBOX)

EN 1. Go to Settings -> Advanced -> Volume & Audio Output
ES 1. Ve a Configuración -> Opciones de sonido -> Sonido de sonido
DE 1. Wählen Sie Einstellungen -> Audiogeräte -> Audiogeräte
PT 1. Digite-a > Definições -> Dispositivos de Áudio -> Áudio
SE 1. Gå till Inställningar -> Ljudinställningar -> Ljudinställningar
DK 1. Indtast indstillinger -> Lyd-udoutput

CHARGING CHARGEMENT

The Stealth™ 600 Gen 2 MAX gives you 48+ hours of rechargeable battery life.
Headset Storage
Rangement du casque

USB TRANSMITTER COMPATIBILITÉ DE L'ÉMETTEUR USB

The USB-A transmitter is equipped with a switch that allows you to change compatibility modes.
XBOX MODE
USB MODE
Xbox Series X|S
PSS™ & PS4™
Xbox One
Windows PC/Mac®
Nintendo Switch™

SETUP FOR USB MODE CONFIGURATION POUR LE MODE USB

1. Put the transmitter into "USB" mode.
2. Put the transmitter into your platform's USB-A port.
3. Power on headset.
4. Wait for headset & transmitter to pair.

ES 1. Pon el transmisor en modo USB.
IT 1. Metti il trasmettitore in modalità "USB".
PT 1. Coloque o transmissor em modo "USB".
SE 1. Ställ in sändaren på "USB"-läget.
NL 1. Zet de zender in de USB-modus.

LED BEHAVIORS ÉTATS DES VOYANTS

HEADSET LED VOYANT DU CASQUE
MEANING SIGNIFICATION
Solid Green Vert et Fixe
Headset and Transmitter Paired Casque et Émetteur Appariés
Breathing Green Clignote en Vert
White Charging & On! Battery Full (En charge et Allumé) Batterie Pleine

TRANSMITTER LED INDICATION INDICATIONS DU VOYANT DE L'ÉMETTEUR

Solid Green Vert et Fixe
Headset and Transmitter Paired Casque et Émetteur Appariés
Double-Blink Green Clignote Deux fois en Vert
Not Paired Non Apparié
Breathing Red Clignote en Rouge
Mic Muted Micro Désactivé

RE-PAIRING NOUVEL APPARIAGE

1. From Off, press and hold the POWER button on the headset until the LED starts flashing rapidly.
2. Insert the transmitter into the console.
3. Press and hold the pin-hole button on the side of the transmitter until the LED starts flashing rapidly.

Regulatory Compliance Statements for the EAR FORCE Stealth™ 600X Gen 2 MAX
Local Restrictions on Radio Usage
FCC Caution
RF Radiation Exposure and European Fair Trade Association Regulatory Compliance

Canadian ICES Statements
This device complies with ICES-001 and ICES-002 of Industry Canada.
Explosion and Radiation RF Risk
This symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste.

Declaration of Conformity
This device complies with the Essential Requirements of the Radio Equipment Directive (RED) of the European Union (2014/53/EU).
Warning! This is a Class B product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

To access the rating labels: Pour accéder à l'étiquette:
1. Remove the left ear pad by pulling the ear pad straight up using your thumb.
2. Once you've released the cloth from the lip on top, pull the ear pad straight back and it should lift right off.
To replace the ear pad, follow the same process in reverse.

Not seeing what you're looking for here?
Visit: turtlebeach.com/support
Rendez-vous sur turtlebeach.com/support
426-231-005-005 RB