

Lane/3000 Desk/1500

User Guide



www.ingenico.com

28-32, boulevard de Grenelle, 75015 Paris - France / (T) +33 (0)1 58 01 80 00 / (F) +33 (0)1 58 01 91 35
Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre

Contents

1	Introduction	4
2	Unpacking	5
3	Recommendations	6
3_1	Safety	6
3_2	Security of your terminal (tampering attempt detection)	7
3_3	Main Characteristics	9
3_3_1	Standard version	9
3_3_2	Dual Head version with 40° pinshield & Touch	9
3_3_3	Powercharacteristics	10
3_4	Functional description	11
3_5	Installation & Connections	12
3_5_1	Positioning the terminal	12
3_5_2	Inserting SAM (Secure access module) and Micro SD	12
3_5_3	Connecting the terminal to the host	16
3_5_4	Setting the Lane/3000 or Desk/1500 on the standpole adaptor	17
3_6	Wireless Connectivity	19
3_6_1	Wi-Fi	19
3_6_2	Bluetooth	19

4_Daily use _____	20
4_1 Card reading _____	20
4_1_1 Swiping a card _____	20
4_1_2 Inserting a smart card _____	20
4_1_3 Reading a contactless card _____	20
4_2 Signature capture (Option) _____	21
4_3 Audio (Option) _____	21
5_Maintenance _____	22
5_1 Cleaning _____	22
5_1_1 Cleaning of the terminal _____	22
5_1_2 Entretien du terminal _____	22
5_1_3 Wartung von Endgeräten _____	23
5_2 Transport and storage _____	23
5_3 Troubleshooting _____	23
6_Cables _____	25
7_Norms & Marking _____	26
7_1 Federal Communications Commission (FCC) Statement _____	26
7_2 Warning to users in Japan _____	27
7_3 Industry Canada (IC) Statement _____	27
7_4 Environment (WEEE, Batteries and Packaging) _____	28
7_5 Marking _____	29

1_Introduction

Thank you for choosing an Ingenico payment terminal.

We recommend you to read carefully this user guide: it gives you the necessary information about safety precautions, unpacking, installation and maintenance of your terminal.

WARRANTY / SECURITY



To benefit from the guarantee-related product, and to respect the security, we ask you to use only the power supply delivered in box with the product, entrusting maintenance operations only to an authorized person. Failure to comply with these instructions will void the manufacturer's responsibility.



This symbol indicates an important Warning.



This symbol indicates a piece of advice.



Unless otherwise indicated, all information in this guide applies to modular terminals (**Lane/3000 & Desk/1500**) and non-modular terminals (**Lane/3000 N & Desk/1500 N**)

References to Lane/3000 and Desk/1500 implicitly refer to Lane/3000 N and Desk/1500 N

● SEAMLESS PAYMENT

2_Unpacking

According to the model, the following items are included in the packaging box (including optional accessories):

> The terminal



This is the standard version.

Other versions are also available without touchscreen, with Dual Head Magnetic stripe reader and or a 40° Pinshield.

The box may also include the following items depending on your working configuration:

- > An installation guide**
- > Cable (specific to connectivity requirements)**
- > Power supply unit and power cord**
- > A stylus**
- > Modules**
- > Screws to fix the main cable and the module**



CAUTION

The power supply unit provided with your equipment is specially designed for it. Do not use any other power supply.



ADVICE

Keep the packaging. It must be re-used whenever the terminal is shipped.

3_Recommendations

3_1 Safety

Power on/Power down - Emergency stop

To power on or power down the terminal, connect or disconnect the power supply from the electric outlet.

Power supply unit



CAUTION

Only use the power supply AC/DC provided with terminal or the power provided by a cash register limited power source (LPS).

The power sources (AC/DC adapter and USB power source) must comply with Standards IEC60950-1:2013 Edition 2.2 and EN60950-1:2006 + A11/2009 + A1/2010 +A12/2011 + A2:2013 or IEC 62368-1

Moreover, they should be Safety Extra-Low Voltage circuits and Power Limited Sources according to clauses 2.2 and 2.5 of these standards

They must be classified **ES1** and **PS2** according to standard **IEC62368-1**



CAUTION

Lithium battery cell

The terminal is fitted with a lithium battery cell which is not accessible to the user. Only a qualified technician is authorized to open the unit and change this component.

Risk of explosion if the battery is replaced by an incorrect type. Dispose of used battery according to the instructions.

Electrical power supply network

The electrical outlet must meet the following criteria:

- Must be installed near the equipment and easily accessible;
- Must meet standards and regulations in the country of use.

Explosion areas

Some regulations restrict the use of radio equipment in chemical plants, fuel depots and any site where blasting may occur. You are urged to comply with these regulations. The terminal shall be protected by a specially fitted and certified cover enabling use in proximity to a fuel pump.

Connection of headset on audio jack



CAUTION

An excessive acoustic pressure of headset can involve deafness!

3_2 Security of your terminal (tampering attempt detection)

Your device fulfils current applicable PCI PTS security requirements. Upon receipt of your terminal you should check for signs of tampering of the equipment. It is strongly advised that these checks are performed regularly after receipt. You should check, for example: that the keypad is firmly in place; that there is no evidence of unusual wires that have been connected to any ports on your terminal or associated equipment, the chip card reader or any other part of your terminal. Such checks would provide warning of any unauthorised modifications to your terminal, and other suspicious behaviour of individuals that have access to your terminal.

Your terminal detects any "tampered state". In this state the terminal will repeatedly flash the message "Alert Iruption!" and further use of the terminal will not be possible. If you observe the "Alert Iruption!" message, you should contact the terminal helpdesk immediately. You are strongly advised to ensure that privileged access to your terminal is only granted to staff that have been independently verified as being trustworthy.

The terminal must never be put in or left at a location where it could be stolen or replaced by another device.



**Warranty label
(On the bottom side of the
terminal)**



WARNING

If the warranty label is torn or removed, the warranty will be void.



CAUTION

Positioning of the Lane/3000 or Desk/1500 on check stand must be in such a way to make cardholder PIN (Personal Identification Number) spying infeasible.

Installing device on an adjustable stand must be in such a way that consumers can swivel the terminal sideways and/or tilt it forwards/backwards to a position that makes visual observation of the PIN-entry process difficult.

Positioning of in-store security cameras such that the PIN-entry keypad is not visible.

NEVER ask the customer to divulge their PIN Code. Customers should be advised to ensure that they are not being overlooked when entering their PIN Code.



CAUTION

This equipment may not be modified, altered or changed in any way without signed written permission from Ingenico

3_3 Main Characteristics

3_3_1 Standard version

Weight (Poids, Gewicht)	254g (8.95 oz)
Size (dimensions, Maße)	180.2 (L) x 83.2 (W) x 43 (H) mm
Display	2.8" backlit LCD, QVGA (800 x 480 pixels)

3_3_2 Dual Head version with 40° pinshield & Touch

Weight (Poids, Gewicht)	276g (9.73 oz)
Size (dimensions, Maße)	180.2 (L) x 85.1 (W) x 48.5 (H) mm
Display	2.8" backlit LCD, QVGA (800 x 480 pixels)
Touchscreen	Capacitive

Operating conditions

Ambient temperature	from 0°C to +40°C (External power supply) from 0°C to +45°C (Other)
Max relative humidity	85% RH non-condensing at +40°C
Max altitude	2000 m

Storage conditions

Storage temperature	-20°C, +55°C
Max relative humidity	85% at +55°C

3_3_3 Power characteristics

Power supply units

The Lane/3000 terminal can be powered by several ways:

- An external power supply unit (modular & non modular) limited to PS2 type
- By USB (5VDC or 12VDC) (modular & non modular) limited to PS2 type
- By POE (Power over Ethernet) (modular)

The characteristics for each type of power supply are detailed hereafter.

● SEAMLESS PAYMENT

Power supply unit

Product	No Modular	Modular
Power Supplies	PSC 16E/A/K-080 PSC16E/A/S-080L6	PSC16E/A/S-080L6
Input voltage	AC 100-240V 50-60Hz	AC 100-240V 50-60Hz
Output voltage	DC 8V 2A (+/- 5%)	DC 8V 2A (+/- 5%)

POE (IEEE 802.3af)	No applicable	DC 48V 1.3W Class 0
--------------------	---------------	------------------------

USB power	DC 5V 0.5A	DC 5V 0.5A
Output voltage	DC 12V 2A	DC 12V 2A

WARNING



The power supply unit provided with your equipment is specially designed for this Ingenico terminal. Do not use any other power supply. The use of a power supply with apparently similar voltage/current characteristics may damage your terminal.

AVERTISSEMENT



Dans le cas où vous choisiriez d'utiliser un bloc alimentation, assurez-vous de n'utiliser que le bloc d'alimentation qui a été conçu spécialement pour votre terminal. N'utilisez pas d'autre bloc d'alimentation. L'emploi d'un bloc d'alimentation présentant des caractéristiques apparemment similaires de tension/intensité peut endommager votre terminal.

● SEAMLESS PAYMENT



WARNHINWEIS

Nur das Netzteil, das speziell für Ihr Gerät ausgelegt wurde, benutzen. Benutzen Sie kein anderes Netzteil. Die Benutzung eines Netzgeräts mit scheinbar ähnlicher Spannung/ Stromstärke kann zur Beschädigung Ihres Terminals führen.

Please note that when powered in 5V some features are deactivated to save as much power as possible: Wifi / Bluetooth, Audio Speaker & Jack, Camera or Biometric reader.

3_4 Functional description



● SEAMLESS PAYMENT

3_5 Installation & Connections

3_5_1 Positioning the terminal

Place the terminal with an easy access to an electrical outlet. Place the terminal away from any heat source and protected from dust, vibrations and electromagnetic radiations (away from video terminals, PC, anti-shoplifting barriers...). The terminal is exclusively made for indoor use.

The Lane/3000 & Desk/1500 device may be mounted on a flat surface, wall, or customer stand.



CAUTION

Do not place the Lane/3000 or Desk/1500 device on a PC monitor, adjacent to an electronically active security tag deactivation system, or near other sources of magnetic fields.

The Lane/3000 or Desk/1500 device must be at least 30 centimeters (12 inches) away from an electronically active type of security tag deactivation pad.

- An electronically active system sends out a powerful and potentially disruptive signal to deactivate the security tag. If the Lane/3000 or Desk/1500 device is placed too close to the system's pad, or placed above the pad, the product may not work properly.
- A passive system is a permanent magnet type that does not send out a signal. This type should not affect the Lane/3000 or Desk/1500 device.

3_5_2 Inserting SAM (Secure access module) and Micro SD




CAUTION

Before starting, switch off the terminal by disconnecting the power supply.


Perform the following operations:

For Modular version, Lane/3000 and Desk/1500

- Unscrew the module and remove it
- Access to SAM and Micro SD is now possible.




- The SAM need to be inserted on the reverse side of the module




• SEAMLESS PAYMENT

- Insert the SAM Card into the slot marked (1), (2) or (3) by sliding it. Take care to ensure that the SAM Card is inserted in the correct manner. The cut corner must be positioned as indicated on the figure below.




- The Micro SD is located on the side of the module as shown in this drawing:




- Slide back the module inside the terminal and screw it tight

For Non Modular version, Lane/3000 N and Desk/1500 N, there is no Micro SD and only one SAM (option).

- To insert the SAM, remove the SAM door



- Then slide the SAM in the reader :



● SEAMLESS PAYMENT



CAUTION

Do not use any tools when installing or removing the SAM Card or Micro SD.




WARNING

During this operation, it is necessary to be in an ESD protected environment. As this is not very easy, it is recommended to make this operation using ESD shoes for example.

3_5_3 Connecting the terminal to the host

**CAUTION**

Connecting must be made when power supply unit is not plugged in the cable.



- Flip the terminal. There is one port on the back for power and communications.
- Connect the cable on the terminal.
- Connect the other end to the power supply unit and a Host (PC / cash register...).
- Plug the power supply into the mains.




WARNING

The main port at the back must not be used to connect an video cable.
Only connect cables provided by Ingenico.


Note : 2 screws can be added (M2.5 x 8) to hold more firmly the cable to the terminal.

3_5_4 Setting the Lane/3000 or Desk/1500 on the standpole adaptor

Install the terminal on a flat surface is not possible on the Lane/3000 or Desk/1500 as is. It is designed to be fitted on a standpole adaptor. The specific pattern by Ingenico is also available on the Lane/3000 or Desk/1500.



To fit the Lane/3000 or Desk/1500 to the stand pole adaptor, it only requires to slide down the terminal until a click sound:



The Lane/3000 or Desk/1500 is now ready to use:



● SEAMLESS PAYMENT

3_6 Wireless Connectivity

3_6_1 Wi-Fi

Wifi and Bluetooth connectivity are optional and available only on modular version terminal.

This feature is useful for wireless connect your terminal to the IP network avoiding the cabling task.

Feature	Dualband : 2.4 GHz and 5 GHz Wi-Fi
Chipset	Marvell 88W8782
Standard compliance	802.11 a/b/g/n, SISO, 2.4GHz and 5GHz, HT20&HT40
Radio transfer rate	From 1 Mbit/s to 135 Mbit/s
Range & Output power	Indoor : 70m typical, mini 100m in free sight / 200mW
Home security	WPA, WPA2
Enterprise security	EAP-MD5, EAP-TLS, EAP-TTLS, EAP-PEAPv0, EAP-SIM

3_6_2 Bluetooth

Feature	Bluetooth V2.0
Chipset	BC08, CSR8811 http://www.csr.com/sites/default/files/csr8811.pdf
Standard compliance	Bluetooth 4.0 (Frequency : 2.4Ghz) Bluetooth 4.2 planned on roadmap (Frequency : 2.4 Gz)
Profile	SPP - A2DP - Other profile to be analyzed on request
Radio transfer rate	1 Mbit/s - 3Mbit/s (EDR)
Number of supported links on	1 open link to PCL
SPP	4 reserved for peripherals (barcode, printer, ...)
Range	Bluetooth Class 2 - max 10m in free sight
Antenna gain	0 dBi
Tune up information	+2dBm +2dBm/-4dBm

● SEAMLESS PAYMENT

4_Daily use

4_1 Card reading

4_1_1 Swiping a card

- Insert the card manually in the reader, magnetic stripe facing the main body of the terminal, and slide the card from the rear to the front in a continuous motion for best results.



Swipe the card with constant speed, neither too slowly nor too fast, to maximize the reading efficiency and avoid annoying repetitions.

4_1_2 Inserting a smart card

- Chip cards should be inserted into your terminal as illustrated with the chip facing up and into the card reader.



4_1_3 Reading a contactless card

- Bring the card to the active zone above the contactless logo (at about 1cm).
- Keep the card close to the contactless logo during the transaction.

Your contactless terminal have four contactless status lights displayed on the screen.



- When a contactless transaction is started the first (left hand) status light will be lit steadily; this indicates that the contactless is in use but a card is not being read.
- When a contactless card is presented to the contactless active zone during a transaction the second, third and fourth status lights will be lit in turn. The card read is successful when all four status lights are lit and a confirmation tone can be heard.

● SEAMLESS PAYMENT



CAUTION

Do not stick any label onto the contactless active zone. It can decrease seriously contactless efficiency.



CAUTION


Avoid metallic parts around the contactless area.

4_2 Signature capture (Option)

- This is an option
- Signature is available on the touchscreen.

4_3 Audio (Option)

A speaker is available there is also an Audio jack. When a headset is plugged in, there is no more sound from the speaker.

- The audio jack  is located next to the card reader.
- This option is not designed to play music, but to facilitate the use by blind people.
- The jack is 3.5mm, 32 ohms impedance.

5_Maintenance

5_1 Cleaning

5_1_1 Cleaning of the terminal



CAUTION

Before making any operations of maintenance in the terminal, make sure that the power supply is disconnected.

First of all, unplug all the wires from the terminal.
Good rules for proper cleaning of the terminal are:

- Use Ingenico Cleaning kit : <http://www.ingenico.cleaningcards.com/>
- Do not clean the electrical connections.
- Do not use in any case, solvents, detergents or abrasive products:
Those materials might damage the plastic or electrical contacts.
- Avoid exposing the terminal to the direct rays of the sun.
- Do not put anything into the slot of the smart card reader

5_1_2 Entretien du terminal



ATTENTION

Assurez-vous que tous les câbles sont bien débranchés du terminal avant toute intervention de maintenance sur le terminal.

Avant tout, débranchez tous les câbles du terminal.
Pour bien nettoyer le terminal :

- Utilisez les kits de nettoyage Ingenico : <http://www.ingenico.cleaningcards.com/>
- Ne nettoyez pas les connexions électriques.
- N'utilisez jamais de solvants, de détergents, d'alcool ou de produits abrasifs :
Ces produits peuvent endommager le plastique ou les contacts électriques.
- Évitez d'exposer le terminal aux rayons directs du soleil.
- N'insérez rien dans la fente du lecteur de carte.

5_1_3 Wartung von Endgeräten



ACHTUNG

Stellen Sie vor jeglicher Wartungsarbeit an dem Terminal sicher, dass die Stromversorgung unterbrochen ist

Als erstes alle Kabel vom Terminal trennen.

Regeln für eine ordnungsgemäße Reinigung des Terminals :

- Für die Außenseite des Terminals, Ingenico Cleaning kits benutzen: <http://www.ingenico.cleaningcards.com/>
- Keine elektrischen Anschlüsse reinigen.
- Auf keinen Fall Lösungsmittel, Waschmittel oder Scheuermittel verwenden:
diese Mittel können den Kunststoff oder elektrische Kontakte beschädigen.
- Das Terminal keiner direkten Sonneneinstrahlung aussetzen.
- Nichts in den Schlitz des Chipkartenlesers einführen.



CAUTION

Before making any operations of maintenance in the terminal, make sure that the power supply is disconnected.

5_2 Transport and storage

- Use the original packaging for storage or returning the unit.
- Disconnect all cables from the terminal during the transport.

5_3 Troubleshooting

Device is not working

- Make sure that the Lane/3000 or Desk/1500 connector is fully inserted into the back of the device.
- Restart the device.
- If you have another working Lane/3000 or Desk/1500 device, swap the devices to determine if the problem is with the device, cable, POS, or power supply.
- If the Lane/3000 or Desk/1500 device is directly connected to a host, reset the host by turning it off and back on again.

● SEAMLESS PAYMENT

Magnetic Card Reader Does Not Work Properly

- When sliding the card through the reader, make sure that the magnetic stripe on the card is facing the Lane/3000 or Desk/1500 display screen (see Swiping a Magnetic Stripe Card).
- Swipe the card at a faster or middle steady speed.
- Inspect the magnetic stripe on the card to make sure it is not scratched or badly worn.
- Security tag deactivation system could disturb the magnetic card reader
- To determine if the problem is with the card :
 - a. If your host device has a magnetic stripe reader, try swiping the card there.
 - b. If you have another working Lane/3000 or Desk/1500 device, try swiping the card there.

Smart Card Reader Does Not Work Properly

- Make sure you have inserted correctly the smart card into the smart card reader and removed the card only after the transaction

MicroSD Card Reader Does Not Work Properly

- Make sure you have inserted correctly the microSD card into the card reader.
- Check that the card capacity is not higher than 32GB.

Touchscreen / Signature Capture Does Not Work Properly

- Make sure you use the correct power supply.
- Replace the stylus



WARNING

Changes or modifications to this device not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

6_Cables

The terminal can be connected to the host by several ways, with optional cables :


- High speed USB device
- Ethernet
- RS232

Most of the cables used with iSC and iPP ranges are compatible with the Lane/3000 or Desk/1500.

We advise to check with your reseller their compatibility if you plan to replace an iSC480 / ISC250 / ISC Touch 250 by a Lane/3000 or Desk/1500.

Following are some examples of accessories that can be used to connect the Lane/3000 or Desk/1500. This list is not exhaustive. Please contact your reseller for more information.

- **RS232 cable (optional)**



- **USB cable (optional)**


References : 296111170AC (length 2m)



- **USB powered 12V cable (optional)**



● SEAMLESS PAYMENT



7_Norms & Marking

7_1 Federal Communications Commission (FCC) Statement

15.21 You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 (a) (3) This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference and
- 2) This device must accept any interference received, including interference that may cause undesired operation of the device.

The device complies with FCC radiation exposure limits set forth for general population (uncontrolled exposure). This device must not be collocated or operating in conjunction with any other antenna or transmitter.

7_2 Industry Canada (IC) Statement.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1) this device may not cause interference, and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- 1) l'appareil ne doit pas produire de brouillage, et
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

3)
Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

"This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions : (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with ISED radiation exposure limits set forth for general population. This device must not be collocated or operating in conjunction with any other antenna or transmitter. Ce présent équipement est conforme aux limites d'exigences d'exposition RF. Cet équipement ne doit pas être installé à proximité ou être utilisé en conjonction avec un autre transmetteur ou antenne.

7_3 WARNING TO USERS IN JAPAN.

Japanese Radio Law and Japanese Telecommunications Business Law Compliance.

This device is granted pursuant to the Japanese Radio Law (電波法) and the Japanese Telecommunications Business Law (電気通信事業法)

This device should not be modified (otherwise the granted designation number will become invalid)

7_4 Environment (WEEE, Batteries and Packaging)

This product is labeled in accordance with European Directives 2012/19/EU concerning Waste Electrical and Electronic Equipment (WEEE) and 2006/66/EC concerning Batteries and Accumulators. Those provisions are requiring producers and manufacturers to become liable for take-back, treatment and recycling upon end of life of equipment and batteries.



The associated symbol means that WEEE and waste batteries must not be thrown away but collected separately and recycled.

Ingenico ensures that efficient collection and recycling schemes are set-up for WEEE and batteries according to the local regulation of your country. Please contact your resellers for more detailed information about the compliance solution in place for disposing of your old product and used batteries.

Packaging waste must also be collected separately to assure a proper disposal and recycling.

Please note that proper recycling of the electrical and electronic equipment and waste batteries will ensure safety of human health and environment.

7_5 Marking

Below, you will find the different symbols used on the product and its power supply.



The CE marking is the manufacturer's declaration that the product meets the requirements of the applicable EC directives. The CE mark is a mandatory conformity marking for certain products sold within the European Economic Area (EEA).



This TÜV symbol shows consumers at a glance that a product has been examined by neutral experts and that there are no safety concerns



The UL mark appears on end products and complete components suitable for factory and field installation. All of the products carrying these marks are covered by our Follow-Up Services program to determine that products continue to be manufactured in compliance with UL's safety requirements.



The RCM mark will be the only mark to indicate compliance with the Australian Communications and Media Authority's (ACMA) regulatory arrangements for telecommunications, radio, EMC and electromagnetic energy (EME).



The C-Tick is an identification trademark registered to the Australian Communications Media Authority (ACMA). The C-Tick mark signifies that the labelled electronic device is compliant with applicable electromagnetic compatibility (EMC) requirements



Waste of Electrical and Electronic Equipment (WEEE) symbol indicates that when the end-user wishes to discard this product, it must be sent to separate collection facilities for recovery and recycling. By separating this product from other household-type waste, the volume of waste sent to incinerators or landfills will be reduced and natural resources will thus be conserved.



● SEAMLESS PAYMENT



This logo indicates that the product operates with an alternative voltage. This symbol is followed by the ratings (voltage and current for instance)



This logo indicates that the product operates with a continuous voltage. This symbol is followed by the ratings (voltage and current for instance)



Mark indicating a power supply meets the level VI requirements.



Double insulated or class 2 electrical appliances are products that have been designed in a way so as not to require a safety connection to electrical earth (These products must NOT have a safety connection to Earth).



Indoor use symbol.

NOTES

"This Document is Copyright © 2019 by INGENICO Group. INGENICO retains full copyright ownership, rights and protection in all material contained in this document. The recipient can receive this document on the condition that he will keep the document confidential and will not use its contents in any form or by any means, except as agreed beforehand, without the prior written permission of INGENICO. Moreover, nobody is authorized to place this document at the disposal of any third party without the prior written permission of INGENICO. If such permission is granted, it will be subject to the condition that the recipient ensures that any other recipient of this document, or information contained therein, is held responsible to INGENICO for the confidentiality of that information.

Care has been taken to ensure that the content of this document is as accurate as possible. INGENICO however declines any responsibility for inaccurate, incomplete or outdated information. The contents of this document may change from time to time without prior notice, and do not create, specify, modify or replace any new or prior contractual obligations agreed upon in writing between INGENICO and the user.

INGENICO is not responsible for any use of this device, which would be non-consistent with the present document.

All trademarks used in this document remain the property of their rightful owners."

Your contact



www.ingenico.com

28-32, boulevard de Grenelle, 75015 Paris - France / (T) +33 (0)1 58 01 80 00 / (F) +33 (0)1 58 01 91 35
Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre

● SEAMLESS PAYMENT