


# 1 CONDUCTED AND RADIATED MEASUREMENT PHOTO


## 1.1 Conducted emission



Configuration n°1 (USB Mode, 322A-0101)



Configuration n°2 (RS232 Mode, 312A-0101)



## 1.2 Radiated emission



Configuration n°1 (USB Mode, 322A-0101)



Configuration n°2 (RS232 Mode, 312A-0101)

