




Radiated emission test setup – RS232 mode

1.2 Radiated emissions



Radiated emission test setup – USB mode



Radiated emission test setup – RS232 mode