




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Left-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_

Right-Ant1-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_Right-Ant1-PASS


NTVN-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge\_1RB\_Right-Ant1-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-Ant1-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-Ant1-PASS






NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-A

nt1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-A

nt1-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-A

nt1-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-A

nt1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer\_Full-A  
nt1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_  
Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_  
Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_  
Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_



Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_

Left-Ant1-PASS






NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_

Right-Ant1-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_

Right-Ant1-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_


Right-Ant1-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_


Right-Ant1-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_ Right-Ant1-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_ Right-Ant1-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge\_1RB\_ Right-Ant1-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS







NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB\_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Left-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Left-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Left-Ant1-PASS





NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Left-Ant1-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge\_1RB  
 \_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer\_Full-A

nt1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer\_Full-A

nt1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer\_Full-A


nt1-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer\_Full-A

nt1-PASS






NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outter\_Full-A  
 nt1-PASS




NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outter\_Full-A  
 nt1-PASS



NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outter\_Full-A  
 nt1-PASS



NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_  
 Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_  
 Right-Ant1-PASS






NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_

Right-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_


Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge\_1RB\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer\_Full-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Edge\_1RB  
 \_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Edge\_1RB  
 \_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Edge\_1RB  
 \_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Edge\_1RB  
 \_Left-Ant1-PASS