


NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_L-ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_L-ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_L-ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_L-ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_

Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_

Left-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_

Left-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_

Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_Right-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_Right-Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_ Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-16QAM-Edge_1RB_ Right-Ant2-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A nt2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A nt2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A

nt2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A

nt2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A

nt2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A


nt2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Outer_Full-A
 nt2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_
 Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_
 Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_
 Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Left-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Left-Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-L-CP-64QAM-Edge_1RB_

Right-Ant2-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-

Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Outer_Full-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB_Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB_Left-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Left-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Left-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
_Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
_Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
_Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
_Right-Ant2-PASS





NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Right-Ant2-PASS



NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-L-CP-256QAM-Edge_1RB
 _Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer_Full-A

nt2-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer_Full-A

nt2-PASS





NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer_Full-A

nt2-PASS





NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outer_Full-A

nt2-PASS




NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outter_Full-A
nt2-PASS

NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outter_Full-A
nt2-PASS



NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Outter_Full-A
nt2-PASS

NTVN-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_L
eft-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_L
eft-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_L
eft-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_L
eft-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_L
eft-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_ Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_ Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_ Right-Ant2-PASS


NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_ Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-QPSK-Edge_1RB_Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-M-CP-16QAM-Outer_Full-Ant2-PASS