





NTNV-N78-3450-3550-PC2-30-100-H-CP-QPSK-Edge\_1RB\_Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Outer\_Full-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Left-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Left-Ant2-PASS







NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_ Left-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_ Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_ Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_ Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Right-Ant2-PASS


NTNV-N78-3450-3550-PC2-30-100-H-CP-16QAM-Edge\_1RB\_

Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-


Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-

Ant2-PASS







NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Outer\_Full-Ant2-PASS


NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_Left-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Left-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Right-Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Right-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_

Right-Ant2-PASS



NTVN-N78-3450-3550-PC2-30-100-H-CP-64QAM-Edge\_1RB\_


Right-Ant2-PASS



NTVN-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full

-Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full  
 -Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full  
 -Ant2-PASS





NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full  
 -Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full  
 -Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full  
 -Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-H-CP-256QAM-Outer\_Full  
 -Ant2-PASS




NTVN-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 Left-Ant2-PASS

NTVN-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Left-Ant2-PASS


NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Left-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Left-Ant2-PASS


NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Left-Ant2-PASS






NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Left-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS




NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS



NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS

NTNV-N78-3450-3550-PC2-30-100-H-CP-256QAM-Edge\_1RB  
 \_Right-Ant2-PASS