




NTNV-N41-PC2-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-30-1000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-1000-3000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15 -Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant 1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Left-30-1000-A nt1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Left-1000-3000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Left-3000-1800
0-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Left-18000-300
00-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Right-0.009-0.
15-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Right-0.15-30-A
nt1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Right-30-1000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Right-1000-300-0-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC2-30-90-M-DFT-QPSK-Edge_1RB_Right-18000-30000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Left-0.15-30-Ant1-PASS



NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Left-1000-3000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Left-3000-1
8000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Left-18000-3
0000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-0.009-
0.15-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-0.15-3
0-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-30-1000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-1000-3000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15 -Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant 1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Left-30-1000-A nt1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Left-1000-3000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Left-3000-1800
0-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Left-18000-3000
0-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-0.009-0.1
5-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-0.15-30-A
nt1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-30-1000-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-1000-300-0-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-3000-180-00-Ant1-PASS




NTNV-N41-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-18000-30-000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Left-1000-3000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Left-3000-18000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Left-18000-30000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Right-0.009-0.15-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Right-0.15-30-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Right-30-100-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Right-100-3000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Right-3000-18000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB_Right-18000-30000-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-0.009-0.1
5-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-0.15-30-An
t1-PASS




NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-30-1000-
Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-1000-3000
-Ant1-PASS




NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-3000-18000-Ant1-PASS



NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Left-18000-30000-Ant1-PASS



NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Right-0.009-0.15-Ant1-PASS



NTNV-N41-PC2-30-100-L-DFT-QPSK-Edge_1RB_Right-0.15-30-Ant1-PASS