




NTVN-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Left-3000-1800  
 0-PASS





NTVN-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Left-18000-300  
 00-PASS



NTVN-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Right-0.009-0.  
 15-PASS





NTVN-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Right-0.15-30-P  
 ASS




NTNV-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Right-30-1000-PASS

NTNV-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Right-1000-3000-PASS




NTNV-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Right-3000-18000-PASS


NTNV-n41-PC1.5-30-100-L-CP-QPSK-Edge\_1RB\_Right-18000-30000-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Left-0.009-0.1  
 5-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Left-0.15-30-PA  
 SS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Left-30-1000-  
 PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Left-1000-3000  
 -PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Left-3000-180  
 00-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Left-18000-300  
 00-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Right-0.009-0.  
 15-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Right-0.15-30-P  
 ASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Right-30-1000  
-PASS



NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Right-1000-300  
0-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Right-3000-18000-PASS  
000-PASS




NTNV-n41-PC1.5-30-100-M-CP-QPSK-Edge\_1RB\_Right-18000-30000-PASS  
000-PASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Left-0.009-0.1  
 5-PASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Left-0.15-30-PA  
 SS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Left-30-1000-P  
 ASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Left-1000-3000-P  
 PASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Left-3000-180  
00-PASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Left-18000-300  
00-PASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Right-0.009-0.  
15-PASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Right-0.15-30-P  
ASS




NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Right-30-1000  
 -PASS



NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Right-1000-300  
 0-PASS



NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Right-3000-18000  
 000-PASS



NTNV-n41-PC1.5-30-100-H-CP-QPSK-Edge\_1RB\_Right-18000-30000  
 000-PASS