




NTNV-N48-PC3-30-20-H-CP-16QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-20-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-20-H-CP-16QAM-Edge_1RB_Right-Ant1-PAS




NTNV-N48-PC3-30-20-H-CP-64QAM-Outer_Full-Ant1-PASS


S



NTNV-N48-PC3-30-20-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-20-H-CP-64QAM-Edge_1RB_Right-Ant1-PASS



NTNV-N48-PC3-30-20-H-CP-256QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-20-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-20-H-CP-256QAM-Edge_1RB_Right-Ant1-PA

SS




NTNV-N48-PC3-30-30-L-DFT-PI2BPSK-Edge_1RB_Left-Ant1-PA


SS



NTNV-N48-PC3-30-30-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N48-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-Ant1-PASS



NTNV-N48-PC3-30-30-L-DFT-QPSK-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-L-DFT-16QAM-Edge_1RB_Left-Ant1-PAS


S



NTNV-N48-PC3-30-30-L-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-L-DFT-16QAM-Outer_Full-Ant1-PASS





NTNV-N48-PC3-30-30-L-DFT-64QAM-Edge_1RB_Left-Ant1-PAS

S



NTNV-N48-PC3-30-30-L-DFT-64QAM-Outer_Full-Ant1-PASS


NTNV-N48-PC3-30-30-L-DFT-64QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-L-DFT-256QAM-Edge_1RB_Left-Ant1-PA


NTNV-N48-PC3-30-30-L-DFT-256QAM-Outer_Full-Ant1-PASS

SS




NTVN-N48-PC3-30-30-L-DFT-256QAM-Outer_Full-Ant1-PASS

NTVN-N48-PC3-30-30-L-CP-QPSK-Edge_1RB_Left-Ant1-PASS




NTVN-N48-PC3-30-30-L-CP-QPSK-Outer_Full-Ant1-PASS

NTVN-N48-PC3-30-30-L-CP-QPSK-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-L-CP-16QAM-Edge_1RB_Left-Ant1-PASS




NTNV-N48-PC3-30-30-L-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-L-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-L-CP-64QAM-Edge_1RB_Left-Ant1-PASS



NTNV-N48-PC3-30-30-L-CP-64QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-L-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-L-CP-256QAM-Edge_1RB_Left-Ant1-PAS





NTNV-N48-PC3-30-30-L-CP-256QAM-Outer_Full-Ant1-PASS

S




NTVN-N48-PC3-30-30-L-CP-256QAM-Outer_Full-Ant1-PASS

NTVN-N48-PC3-30-30-H-DFT-PI2BPSK-Outer_Full-Ant1-PASS



NTVN-N48-PC3-30-30-H-DFT-PI2BPSK-Outer_Full-Ant1-PASS


NTVN-N48-PC3-30-30-H-DFT-PI2BPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N48-PC3-30-30-H-DFT-QPSK-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-H-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-DFT-QPSK-Edge_1RB_Right-Ant1-PAS





NTNV-N48-PC3-30-30-H-DFT-16QAM-Outer_Full-Ant1-PASS

S




NTNV-N48-PC3-30-30-H-DFT-16QAM-Outer_Full-Ant1-PASS

NTNV-N48-PC3-30-30-H-DFT-16QAM-Edge_1RB_Right-Ant1-PA SS



NTNV-N48-PC3-30-30-H-DFT-64QAM-Outer_Full-Ant1-PASS


NTNV-N48-PC3-30-30-H-DFT-64QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-H-DFT-64QAM-Edge_1RB_Right-Ant1-PA SS



NTNV-N48-PC3-30-30-H-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-H-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-DFT-256QAM-Edge_1RB_Right-Ant1-PASS



NTNV-N48-PC3-30-30-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-CP-QPSK-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-H-CP-QPSK-Edge_1RB_Right-Ant1-PASS



NTNV-N48-PC3-30-30-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-CP-16QAM-Edge_1RB_Right-Ant1-PASS



NTNV-N48-PC3-30-30-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-CP-64QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-30-H-CP-64QAM-Edge_1RB_Right-Ant1-PAS

S



NTNV-N48-PC3-30-30-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-30-H-CP-256QAM-Edge_1RB_Right-Ant1-PASS


SS



NTNV-N48-PC3-30-40-L-DFT-PI2BPSK-Edge_1RB_Left-Ant1-PA SS




NTNV-N48-PC3-30-40-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-Ant1-PASS



NTNV-N48-PC3-30-40-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-16QAM-Edge_1RB_Left-Ant1-PAS

S



NTNV-N48-PC3-30-40-L-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-64QAM-Edge_1RB_Left-Ant1-PASS


S




NTNV-N48-PC3-30-40-L-DFT-64QAM-Outer_Full-Ant1-PASS




NTNV-N48-PC3-30-40-L-DFT-64QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-40-L-DFT-256QAM-Edge_1RB_Left-Ant1-PA SS



NTNV-N48-PC3-30-40-L-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-40-L-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-N48-PC3-30-40-L-CP-QPSK-Edge_1RB_Left-Ant1-PASS