




NTNV-N77-3700-3980-PC2-30-50-H-DFT-PI2BPSK-Outer_
Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-50-H-DFT-PI2BPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-50-H-DFT-QPSK-Outer_Full
-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-50-H-DFT-QPSK-Edge_1RB_Rig
ht-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-60-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-L-DFT-PI2BPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-L-DFT-QPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-H-DFT-PI2BPSK-Outer_
Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-H-DFT-PI2BPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-H-DFT-QPSK-Outer_Full
-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-60-H-DFT-QPSK-Edge_1RB_Rig
ht-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-L-DFT-PI2BPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-L-DFT-QPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-H-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-H-DFT-PI2BPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-H-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-80-H-DFT-QPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-L-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-L-DFT-PI2BPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-L-DFT-QPSK-Edge_1RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Outer
_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1RB
_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Outer_Fu
II-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_Le
ft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-H-DFT-PI2BPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-H-DFT-PI2BPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-H-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-H-DFT-QPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R


B_Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-10-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-QPSK-Edge_1RB_L
 eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-QPSK-Edge_1RB_L
 eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-L-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-10-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-10-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS