


NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-20-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS


NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R


B_Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-L-DFT-QPSK-Edge_1RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS


NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_


Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_
 Left-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_
 Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_


Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_


Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-40-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS