


NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_
 Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_
 Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_ Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_


Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-50-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R_B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-PI2BPSK-Edge_1R_B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_


Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_
Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R

B_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R

B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R

B_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R

B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R


B_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R


B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L
 eft-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L
 eft-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L eft-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L eft-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_L
 eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_
 Right-Ant1-PASS