





NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_
 Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_
 Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_


Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-M-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_
Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS





NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
 B_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
 B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge_1RB_L
eft-Ant1-PASS

