



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_  
 Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_  
 Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_  
 Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
 B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-PI2BPSK-Edge\_1R  
 B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_  
 Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_  
 Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_



Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_



Right-Ant1-PASS






NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-80-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R\_B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-PI2BPSK-Edge\_1R\_B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS


NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_



Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS






NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
 B\_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
 B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
 B\_Left-Ant1-PASS

NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
 B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
 B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-90-L-DFT-PI2BPSK-Edge\_1R  
 B\_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-90-L-DFT-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-90-L-DFT-QPSK-Edge\_1RB\_L  
 eft-Ant1-PASS