




NTNV-N78-3700-3800-PC2-30-10-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_


Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_  
Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_  
Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_  
Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_  
Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS





NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS





NTNV-N78-3700-3800-PC2-30-10-H-DFT-QPSK-Edge\_1RB\_

Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS


NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS

NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS






NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
 B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
 B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
 B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
 B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-L-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_L  
eft-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_L  
eft-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_L  
eft-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_L  
eft-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_L eft-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_L eft-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-L-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS





NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS





NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS

NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS

NTNV-N78-3700-3800-PC2-30-15-M-DFT-PI2BPSK-Edge\_1R  
B\_Right-Ant1-PASS







NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_  
Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_  
Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_  
Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_  
Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Left-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS




NTNV-N78-3700-3800-PC2-30-15-M-DFT-QPSK-Edge\_1RB\_ Right-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS



NTNV-N78-3700-3800-PC2-30-15-H-DFT-PI2BPSK-Edge\_1R  
B\_Left-Ant1-PASS