

TUNE UP PROCEDURE

The Knee Balancer does not have a tune up procedure. The transmission frequency and level is set during manufacturing to a fixed value based on settings stored in memory in the Knee Balancer. These settings cannot be changed after manufacturing.