









Ecolink 1118D

S2

J2

PC0

UCC

PC2

J1

PA5

nRESET

TP7

TP11

TP5

PA1

JTCK

PC1

D5

S1

TP10

TP6

PY1

PY2

TP9

TP1

TP3

TP2