

Antenna Specification
WST-212
Rev 1

The WST-212 transmitter uses a loop antenna (-15 dBi).
The loop antenna consists of copper-clad wire elevated slightly above the printed circuit board. The antenna is not replaceable by the user.