

BOOX Note2

Quick Start Guide

Please refer to the pre-loaded User Manual or official website technical support for detail guidance

www.boox.com

BOOX Note2 x 1

Quick Start Guide x 1

Warranty Sheet x 1

Stylus pen x 1

USB-C x 1

Four icons representing accessories: Adapter, TF card reader, BOOX Holder, and Protective Case.

This section contains two line drawings. The left drawing shows a hand holding a tablet, with a jagged crack appearing on the screen. The right drawing shows a liquid being poured from a cup onto a rectangular object, representing the BOOX device.

This guide can not contain enough information limited pages, please refer to the User Manual of each model for detail instruction. Product pictures in this guide are for reference only. Product ID including but not limited to colors and functions are subject to the actual product.

Onyx International Inc. reserves the right to modify the content of the Quick Start Guide and User Manual without further notice.


Diagram illustrating the front view of the device. The display area is labeled ①, and the home button is labeled ②.

Diagram of the back cover of the BOOX T62. The cover is white with a black spine. The text "BOOX" and "T62" are printed vertically on the spine. Callout 3 points to the bottom-left corner, callout 4 points to the bottom edge, and callout 5 points to the bottom-right corner.


The screenshot shows the OLYX application interface. At the top, there is a status bar (1) with a battery icon and the text 'Status Bar'. Below this is a library content area (2) displaying a grid of document thumbnails, including one titled '1. About OLYX'. The main menu (3) is located below the library content, showing a list of documents. The toolbar (4) is positioned below the main menu, containing icons for various functions. The reading section (5) displays the content of the selected document, '1. About OLYX', which includes a paragraph about the OLYX project and a list of links. The reading menu (6) is located at the bottom of the screen, showing a list of documents.

The screen can be divided into three column

Single tap on the screen



06



1. Slide upwards, turn to previous page;
2. Slide downwards, turn to next page.

- 1. How to turn on/off the device**
 - 1) When your BOOX is off, press power button for 3-5 seconds to turn the device on;
 - 2) When your BOOX is on, press power button for 3 seconds and click "power off" to shutdown the device;
 - 3) When your BOOX is on, press power button for 10 seconds to force shutdown the device;
- 2. How to charge**
 - 1) Recharge your BOOX by connecting it with PC directly;
 - 2) Recharge your BOOX by connecting it with adapter(SV-3A, optional accessory);
 - 3) Signal light is on when your BOOX is charging; the light will be off after battery is fully charged;
 - 4) Full single charge will take around 2 hours (QC3.0).
- 3. How to transfer data**
 - 1) Transfer data by connecting your BOOX with PC via USB-C cable;
 - 2) Transfer data by third-party sync apps between PC and the device via WIFI;
 - 3) Download data or read online by browsing via WIFI;
 - 4) Download data or read online by Login of reading APP via WIFI;
- 4. How to update locally**
 - 1) Download the update package and put it into root directory of local storage;
 - 2) Update your firmware via OTA online;

Note: 1. OTA update only supports some countries or areas. Please consult the local distributor.
2. Please connect the device with power source or PC to make sure of enough power for updating.

- 5. How to preserve your BOOX**
 - 1) Use hard cover to avoid direct striking or pressing against the screen;
 - 2) Put the screen side downwards when your BOOX is not in use; do not put anything in-between of the screen and other flat surface;
 - 3) Don't pile up or store heavy stuff over the device;
 - 4) Keep your BOOX away from all types of liquids;

Made in China
© Onyx International Inc. All rights reserved.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.