QUICK START INSTRUCTION MANUAL

- > Connect the hoses to the Master Control Unit (pump) by aligning the rectangles inside the connector. Tighten the nut to the pump by hand only. DO NOT USE TOOLS and DO NOT OVER-TIGHTEN. Do not forget the washer inside the nut.
- Use the provided phone cord to connect pump and the bed-side charger. Place the pump under the bed and direct the hoses towards the mattress valves.
- To connect the other end of the hoses to the mattress connector, push the quick connector onto the elbow and turn clockwise until locked. There is only one hose for twin or full size mattress.
- > Select the mattress size and speed of modulation at the back of the charger. Place the charger on the night stand next to your bed.
- Connect the pump to a 120VAC wall socket.
- Power on the remote control by moving the slide switch at the bottom of the remote control.
- Wait for the antenna icon to flash. Then link the remote and charger by pressing the FIRM button on the remote. The antenna icon should shut off after linking.
- Lie down on the right side of bed which is the default side. Press the **SOFT** button on the remote control. The bed goes through a sequence of calibration process.
- Press SOFT or FIRM to adjust the softness to your preference.
- > Press the **SIDE** button to change sides of the mattress. The calibration process will start on the left side when **SOFT** is pressed.
- When you find your ideal comfort level, press MEMORY SET for 3 seconds to store your comfort level in memory, or press MEMORY RESTORE for two seconds to retrieve a previously stored setting. To review a stored memory number at any time, press and release either button quickly.
- > Turn on the **AUTO** button the night before if you want to "MAKE BED" in the morning. The mattress resets itself to maximum firm 30 minutes after you have gotten out of bed.
- Press RESET at any time to go to maximum firm or to make your bed manually in the morning.
- If you change a setting at the back of the charger, re-power the pump for the new setting to take effect. Disconnect then reconnect the cord at the back of the charger can also reboot the system.
- Use the buttons at the back of the charger to adjust the bed if the remote control is not available.
- Place the remote control on the charger when not in use.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS PRODUCT WITH ANY SOLID-STATE SPEED CONTROL DEVICE.

- For indoors use only. Do not expose to water or use outdoors.
- Do not pull pump by the supply cord or charger cord.
- This appliance has a polarized plug which one blade is wider than the other. To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- This product is intended for intermittent use only. Do not operate continuously for more than 15 minutes. Allow at least 15 minutes of cooling time between uses.
- Do not block airflows from intake or exhaust.
- Do not cover pump with bed covers, sheets, blankets or any type of fabrics that may restrict airflow or restrict heat dissipation.
- For household bed use only. Any other use may increase safety hazards.
- This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with the appliance.
- The power supply cord is not replaceable by consumers. If the supply cord is damaged, it must be replaced by the manufacturer or its service agents or a similarly qualified person in order to avoid a hazard.
- Unplug or disconnect the appliance from the power supply before servicing.

FCC Statement:

- > This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- > (1) this device may not cause harmful interference, and
- > (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's
- > authority to operate the equipment.
- ➤ NOTE:
- > This equipment has been tested and found to comply with the limits for a
- Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are
- > designed to provide reasonable protection against harmful interference in a
- residential installation. This equipment generates, uses and can radiate radio
- > frequency energy and, if not installed and used in accordance with the
- instructions, may cause harmful interference to radio communications. However,
- there is no guarantee that interference will not occur in a particular installation.
- > If this equipment does cause harmful interference to radio or television reception,
- which can be determined by turning the equipment off and on, the user is
- encouraged to try to correct the interference by one or more of the following
- measures:
- > -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- > -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- > -- Consult the dealer or an experienced radio/TV technician for help.

READ AND SAVE THESE INSTRUCTIONS