3SM S0* WW

Add on to the user guide:

All text concerning the main, power cord and similarly will be taken out of the user guide.

The below text will be add to the user guide on the relevant pages.









When instructions says "Disconnect the main power supply to the products for 1 minute and then reconnect it" it is equivalent to: "Power the unit off (see above) and after 1 minute power the unit on (see above)."

Remember that the batteries will not be charged when the switch is off. So in order to charge the batteries the switch must be on.