



CONSTRUCTION PHOTOS OF EUT


Two antenna connectors <Sample 2, USB Interface >




One antenna connector <Sample 2, USB Interface >



Two antenna connectors <Sample 1, PCIe Interface >




One antenna connector < Sample 1, PCIe Interface >



Antenna 1: DQ661500301(Main) / DQ661500301(Aux)






Antenna 2: 37LX6AATP00 (Tx1) / 37LX6AATP00 (Tx2)




Antenna 3: 37LX7AATP00 (Tx1) / 37LX7AATP00 (Tx2)




Antenna 4: 3ASP8AATP20 (Tx1) / 3ASP8AATP20 (Tx2)




Antenna 5: 25.90675.001 (Rx) / 25.90676.001 (Tx)




Antenna 6: 25.90669.001 (Rx) / 25.90670.001 (Tx)




Antenna 7: 3209970 (Rx) / 3210002 (Tx)




Antenna 8: 25.90598.001 (Rx) / 25.90597.001 (Tx)




Antenna 9: 25.90587.001 (Rx) / 25.90586.001 (Tx)




Antenna 10: 25.90653.001 (Rx) / 25.90654.001 (Tx)




Antenna 11: 25.90649.001 (Rx) / 25.90650.001 (Tx)




Antenna 12: 024-01F0-2242 (Rx) / 024-01F0-2243 (Tx)




Antenna 13: 3176658 (Rx) / 3176674 (Tx)




Antenna 14: WDAN-L1WK1001-DF (Rx) / WDAN-L1WK1002-DF (Tx)




Antenna 15: HMT14-MAIN (Rx) / HMT14-AUX (Tx)




Antenna 16: 25.90700.001 (Rx) / 25.90702.001 (Tx)



Antenna 17: 25.90800.001 (Rx) / 25.90802.001 (Tx)




Antenna 18: APM6P-700033 (Rx) / APM6P-700034 (Tx)




Antenna 19: 14G152168231LV (Rx) / 14G152168131LV (Tx)



Antenna 20: APM6P-700027 (Rx) / APM6P-700029 (Tx)




Antenna 21: 2023940-1 (Rx) / 2023944-1 (Tx)




Antenna 22: APM6P-700028 (Rx) / APM6P-700030 (Tx)




Antenna 23: 2023946-1 (Rx) / 2023950-1 (Tx)




Antenna 24: LX-0980-11-000-R (Rx) / LX-0983-11-000-R (Tx)




Antenna 25: 3172525 (Rx) / 3172566 (Tx)




Antenna 26: LX0970-11-000-R (Rx) / LX0968-11-000-R (Tx)



Antenna 27: WDAN-L1ML3001-DF (Rx) / WDAN-L1ML3002-DF (Tx)



Antenna 28: 3172467 (Rx) / 3172509 (Tx)




Antenna 29: DQ6GC200100 (Rx) / DQ6GC200200 (Tx)




Antenna 30: DQ6GC300100 (Rx) / DQ6GC300200 (Tx)



Antenna 31: QADCPS1_WL_M (Rx) / QADCPS1_WL_A (Tx)




Antenna 32: QADCFL3 WL M (Rx) / QADCFL3 WL A (Tx)




Antenna 33: 25.90929.001 (Rx) / 25.90930.001 (Tx)



Antenna 34: 25.90934.001 (Rx) / 25.90935.001 (Tx)




Antenna 35: 25.90919.001 (Rx) / 25.90920.001 (Tx)



Antenna 36: C-1334-11-000-26 (Rx) / C-1335-11-000-26 (Tx)



Antenna 37: 25.90979.001 (Rx) / 25.90980.001 (Tx)



Antenna 38: 81.EEO15.001 (Main) / 81.EEO15.002 (Aux)



Antenna 39: 81.EHD15.003 (Main) / 81.EHD15.002 (Aux)



Antenna 40: 81.EHD15.005 (Tx1) / 81.EHD15.004 (Tx2)



Antenna 41: 81.EHD15.004 (Main) / 81.EHD15.006 (Aux)




Antenna 42: 81.EHD15.004 (Main) / 81.EHD15.007 (Aux)




Antenna 43: 81.EHD15.G09 (Tx1) / 81.EHD15.G10 (Tx2)




Antenna 44: WDAN-M1WC1001-DF(Main) / WDAN-M1MM1001-DF (Aux)



Antenna 45: SS-03-03-099 (Main) / SS-03-03-100 (Aux)





Antenna 46: WDAN-M1WC1001-DF (Main) / WDAN-M1BN1001-DF (Aux)



Antenna 47: WDAN-M1NY1001-DF (Main)





Antenna 48: WDAN-M1PB1001-DF (Tx1) / WDAN-M1PB1002-DF (Tx2)




Antenna 49: WDAN-M1SN1002-DF(Main) / WDAN-M1SN1001-DF (Aux)


A D T




Antenna 50: WDAN-M1OS1001-DF (Main) / WDAN-M1OS1002-DF (Aux)




Antenna 51: WDAN-M1WC1002-DF (Main) / WDAN-M1WC1001-DF (Aux)



Antenna 52: HFT40 (Tx1) / HFT40 (Tx2)



Antenna 53: HFT60 (Tx1) / HFT60(Tx2)






A D T


Antenna 54: WNC001 (Main) / WNC001(Aux)





Antenna 55: WNC002 (Main) / WNC002 (Aux)




Antenna 56: TBN001 (Main) / TBN001 (Aux)




Antenna 57: TBN003 (Main) / TBN003 (Aux)




Antenna 58: HBY07 (Tx1) / HBY07 (Tx2)




Antenna 59: HBY051 (Tx1) / HBY051 (Tx2)




Antenna 60: HBY052 (Tx1) / HBY052 (Tx2)




Antenna 61: HBY061 (Tx1) / HBY061 (Tx2)





Antenna 62: HBY062 (Tx1) / HBY062 (Tx2)





Antenna 63: HFT65 (Tx1) / HFT65 (Tx2)




Antenna 64: HCT01 (Main) / HCT01 (Aux)






Antenna 65: WDAN-TQ (Tx1) / WDAN-TQ (Tx2)






Antenna 66: TBN005 / TBN006





Antenna 67: WNC004 (Main) / WNC004 (Aux)





Antenna 68: TBN008 (Tx1) / TBN008 (Tx2)




Antenna 69: TBN008 (Tx1) / TBN008 (Tx2)



Antenna 70: TBN008 (Tx1) / TBN008 (Tx2)




Antenna 71: TBN007 (Tx1) / TBN007 (Tx2)



Antenna 72: 03-FR021-016 (Tx1) / 03-FR021-016 (Tx2)




Antenna 73: 81XCAE15.G07 (Main) / 81XCAE15.G08 (Aux)



Antenna 74: AMP8P-700130 (Main) / AMP8P-700131 (Aux)



Antenna 75: WNC005 (Main) / WNC005 (Aux)




Antenna 76: MSA-00005A (Main) / MSA-00005A (Aux)




Antenna 77: WNC003 (Main) / WNC003 (Aux)



Antenna 78: HFS23



Antenna 79: HFS40





Antenna 80: TBN004 (Main) / TBN004 (Aux)





Antenna 81: SKM11WMPB01+C (Tx1), SKM11WMPB02+D (Tx2)





Antenna 82: N01001165001 (Tx1), N01001165001 (Tx2)





Antenna 83: N01001177001 (Tx1), N01001177001 (Tx2)



Antenna 84: N01001175001 (Tx1), N01001176001 (Tx2)





Antenna 85: N01001080001 (Tx1), N01001080001 (Tx2)





Antenna 86: 03-FR021-026 (Tx1), 03-FR021-026 (Tx2)





Antenna 87: 03-FR021-020 (Tx1), 03-FR021-020 (Tx2)





Antenna 88: AMP8P-700167 (Tx1), AMP8P-700167 (Tx2)





Antenna 89: SE-0730G-ECM11 (Tx1), SE-0730G-ECM11 (Tx2)




Antenna 90: 81.EKJ15.G22 (Main), 81.EKJ15.G22 (Aux)




Antenna 91: FL5130-11-002-C (Tx1), FL5130-11-003-C (Tx2)





Antenna 92: B2885050G00003 (Tx1), B2885050G00003 (Tx2)



Antenna 93: QADCFL3_WL_M (Main), QADCFL3_WL_A (Aux)




Antenna 94: HFT60 (Tx1), HFT60 (Tx2)





Antenna 95_ A6P1WFI0100A1 (Main) & A6P1WFI0100A1 (Aux)



A D T




Antenna 96_ 220265-09 (Tx1) & 220265-09 (Tx2)





Antenna 97_ 81XCAE15.G13 (Main) & 81XCAE15.G14 (Aux)





Antenna 98_ SE-042C0-ECL30 (Tx1) & SE-042D0-ECL30 (Tx2)





Antenna 99_ 81.EJZ15.G52 (Main) & 81.EJZ15.G52 (Aux)





Antenna 100_ 81.EJT15.GJC (Main) & 81.EJT15.GJC (Aux)




Antenna 101_ 81.EJT15.GGW (Main) & 81.EJT15.GGW (Aux)




Antenna 102_ 81.EJZ15.G53 (Main) & 81.EJZ15.G53 (Aux)





Antenna 103_ 5002011-1 (TX1) & 5002012-1 (TX2)





Antenna 104_ 5010011-1 (TX1) & 5010012-1 (TX2)




Antenna 105_ AN-070-G(R) (TX1) & AN-070-G(L) (TX2)




Antenna 106_ AN-070-G(R) (TX1) & AN-070-G(L) (TX2)




Antenna 107_ AN-120-F(R) (TX1) & AN-120-F(L) (TX2)




Antenna 108_ AN-120-F(R) (TX1) & AN-120-F(L) (TX2)



Antenna 109_ 5002015-1 (TX1) & 5002016-1 (TX2)



Antenna 110_ 5010015-1 (TX1) & 5010016-1 (TX2)





Antenna 111_ 25.90A0S.001 (Main) & 25.90A0R.001 (Aux)



Antenna 111_ 25.90A0S.001 (Main) & 25.90A0R.001 (Aux)



Antenna 112: AN-PF010008 (Main) & AN-PF010007 (Aux)



Antenna 113: R064018R (Main) & R064019R (Aux)



Antenna 114: 43R-A14001-0300 (Main) & 43R-A14001-0310 (Aux)





Antenna 115: 43R-A15001-0200 (Main) & 43R-A15001-0210 (Aux)





Antenna 116: 43R-A15001-0100 (Main) & 43R-A15001-0110 (Aux)



Antenna 117: 43R-A15001-0300 (Main) & 43R-A15001-0310 (Aux)



Antenna 118: 43R-B13001-0300 (Main) & 43R-B14001-0310 (Aux)



Antenna 119: 43R-DB1401-0200 (Main) & 43R-B13001-0220 (Aux)

